

MCA-527

Digital Multi-Channel Analyzer

Description of the MCA527 Firmware Commands

Exclusion of liability

The information in this document has been carefully reviewed and is believed to be accurate and reliable. However, the GBS Elektronik GmbH assumes no liabilities for inaccuracies in this manual. This manual is subject to change without notice.

Last update: 2019-11-15

Address:

GBS-Elektronik GmbH
Bautzner Landstraße 22
01454 Großserkmannsdorf
Tel.: (0351) 217007-0
Fax: (0351) 217007-21

Internet: <http://www.gbs-elektronik.de>
Email to: kontakt@gbs-elektronik.de

ATTENTION! This description is subject to change. The current one refers to MCA527 firmware version 19.03.

Introduction

The MCA527 provides all MCA166 firmware functions. They are identical or else at least compatible to the MCA166 firmware functions. But there are also entirely new firmware functions. Older software applications that use only the MCA166 firmware functions are still usable to operate the MCA527. However, they waste the new capabilities of the MCA527.

Since the MCA527 can be operated by different interfaces (RS232, RS485, USB or Ethernet) concurrently, the MCA527 grants an execution right for commands which must not be executable by different applications at the same time.

The execution right is granted to that application that calls first such a command. An application keeps the granted execution right as long as it communicates continuously with the MCA527. It loses the execution right when it does not communicate for more than 15 seconds.

The execution right is valid only for one communication path. For example, if an application owns the execution right for the RS232 interface, it has to release that execution right by interrupting the communication for at least 15 seconds before it or another application can obtain the execution right for the Ethernet.

The communication between computer and MCA527 runs in the following way. The computer sends a 12 bytes long command. Each command consists of the preamble (0xA5, 0x5A), the command number (2 bytes), the parameters (6 bytes) and the end flag (0xB9, 0x9B). The MCA527 usually responses immediately, but for some commands the response time is up to 1 second. The result data array is embedded between the preamble and the end flag. The preamble is always 0xA5, 0x5A. The end flag informs about the result of the command according the following table.

0xB9, 0x9B: successful

0xA4 0xAA timeout¹

0xA5 0xAA different baud rates between PC and MCA527²

0xA6 0xAA invalid preamble or end flag³

0xA7 0xAA µSD memory card error

0xA8 0xAA file writing is presently in process, but this is forbidden for this command

0xA9, 0xAA: not handled by this firmware version (either generally or customized)

0xAA, 0xAA: invalid parameter

0xAB, 0xAA: unknown command

0xAC, 0xAA: measurement is running, but stopped measurement is required for this command

0xAD, 0xAA: execution right violation

0xAE, 0xAA: measurement is stopped, but running measurement is required for this command

0xAF, 0xAA: wrong mode for using this command (with this parameters)

¹ Since firmware version 15.00. The timeout for the 12 command bytes is 4 milliseconds. If the bytes are not received within this period, the MCA527 returns this error flag. The same happens if the MCA527 receives too many or too few bytes. In previous firmware versions, the MCA527 had returned 'invalid parameter' for this error.

² Since firmware version 15.00. Each time the MCA527 detects different baud rates between PC and MCA527, it swaps the baud rate and returns this error flag with the new baud rate. In previous firmware versions, the MCA527 had returned 'invalid parameter' for this error.

³ Since firmware version 15.00, an invalid preamble or end flag returns this flag. In previous firmware versions, the MCA527 had returned 'invalid parameter' for this error.

For most commands 136 bytes are returned (preamble = 2 bytes, result data array = 132 bytes, end flag = 2 bytes). But there are also commands with a larger result data array. However, if a command is unsuccessful, then always only 136 bytes are returned.

If the end flag indicates a successful command, the result data array contains the 8 sent data bytes (without preamble and end flag) at byte offset 106 and a two byte checksum at byte offset 126 of the result data array. This both byte offsets apply for almost all commands (including the commands where the result data array is not described because it contains no further data).

For commands that return more than 136 bytes, the sent data bytes and the checksum are returned at another byte offsets within the result data array. See the description for these commands. The checksum is a simple 16-bit sum over all other returned 2-byte words (without preamble and end flag).

For almost all commands, the checksum is a simple 16-bit sum over all other returned 2-byte words (including preamble and end flag).

The commands `CMD_QUERY_SPECTRA` and `CMD_QUERY_SPECTRA_EX` work according to a different rule. They do not return the 8 sent data bytes and the checksum is the 16-bit sum over all sent and returned 2-byte words. The checksum is returned at byte offset 130 of the result data array. (This different rule originates from the MCA166. Because all commands of the MCA166 return always 136 bytes, there is no place for returning the 8 sent data bytes.)

The RS232 interface is able to communicate with 38 400, 115 200 and 307 200 baud, the USB interface communicates additionally with 3 000 000 baud (8 data bits, 1 stop bit, no parity, no flow control). In order to set a baud rate on the MCA527, the desired baud rate has to be set on the computer. Different baud rates on computer and MCA527 causes frame errors. If the MCA527 detects frame errors, it swaps the baud rate (38 400 → 115 200 → 307 200 → 3 000 000 → 38 400) and responses with the new baud rate. Unfortunately, the MCA527 is unable to detect frame errors in all cases. If the current baud rate on MCA527 is 38 400 or 115 200 and the baud rate on the computer is set to 3 000 000, the MCA527 does not detect frame errors and does not swap the baud rate. This behavior has to be considered if the baud rate is set.

There are MCA527 with RS485 interface. About the special functional principle of the RS485 interface, see the document "Description of the MCA527 RS485 Interface" (*MCA527_RS485_XXXX_XX_XX.pdf*).

The Ethernet communication uses the UDP protocol with the destination port 50 000. The preamble of the returned data are prefixed two additional bytes (0xA5, 0x5A) for intern byte alignment within the MCA527.

The MCA527 can be configured to use a fixed customized IP address or to obtain the IP address automatically from a DHCP server or if not available, to use Zero Configuration Networking (also named Automatic Private IP Addressing).

While the MCA527 is writing a file, only the query commands and `CMD_STOP` command are executable. All other commands are ignored and response with an error value. The file writing state is returned by `CMD_QUERY_STATE527_EX`.

[illegible]

Command name	CMD_CLEAR												
Compatibility	Differs to the MCA166 command.												
Execution right	Necessary												
Description	<p>Depending on the parameter: CLEAR_MEASUREMENT_DATA = 0 or 1 CLEAR_ROI = 2 CLEAR_ALL = 3</p> <p>The command clears the measurement data, the ROI limits exclusively or all together. Before the measurement data are cleared, a running measurement is immediately stopped.</p>												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		clear		0				end flag		
Byte string (HEX)	A5	5A	44	00	clear	00	00	00	00	00	B9	9B	

Command name	CMD_SAVE_MCA_STATE											
Compatibility	New MCA527 command (since firmware version 15.07).											
Execution right	Necessary											
Description	<p>Depending on the option: = 0: Deletes only the previously saved MCA state. ≠ 0: Saves the current MCA state.</p> <p>The command is only available for the OEM, Micro and Nano version. The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		option		0				end flag	
Byte string (HEX)	A5	5A	37	01	option _l	option _h	00	00	00	00	B9	9B
Remarks	<p>In Full and Lite version, the current MCA state is saved on the internal EEPROM at shutdown. In OEM (without power module⁴) and Micro version, an orderly shutdown is not possible because the power supply may be disconnect suddenly and without warning. For this reason, this command has been added.</p> <p>If the MCA state needs to be saved for the next session, the command has to be executed before the MCA527 is disconnected from the power supply. The MCA state remains saved within the EEPROM until it is explicitly deleted or overwritten. Even if the MCA527 is reset by CMD_INIT, the EEPROM is not erased.</p>											

5

MCA Mode Commands:

Command name	CMD_SET_GENERAL_MODE												
Compatibility	New MCA527 command												
Execution right	Necessary												
Description	<p>The MCA527 is not only usable as a MCA. It can also alternatively be used as an oscilloscope, as a transient recorder or in a list mode.</p> <p>Depending on the parameter, the MCA527 serves as:</p> <p>0 = MCA 1 = Transient recorder (records ADC raw data⁵) 2 = Oscilloscope 3 = List mode 1: Time stamp recorder (level triggered signals)^{6,7} 4 = List mode 2: Time stamp recorder (edge triggered signals)⁷ 5 = List mode 3: Time stamp recorder (AHRC⁸ = analog high rate counting)⁷ 6 = List mode 4⁹: 7 = List mode 5¹⁰:</p> <p>The command sets the MCA527 to the required general mode. Previously acquired data are cleared. The command is ignored and responded with an error value if a measurement is still running.</p>												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		mode		0				end flag		
Byte string (HEX)	A5	5A	05	01	mode	00	00	00	00	00	00	B9	9B
Remarks	The oscilloscope mode is described in the document “Description of the MCA527 Oscilloscope Mode” (MCA527_Oscilloscope_Mode_XXXX_XX_XX.pdf).												

Command name	CMD_SET_MODE												
Compatibility	Identical to the MCA166 command.												
Execution right	Necessary												
Description	Depending on the parameter: MODE_MCA = 0 or MODE_MCS = 1, the command sets the MCA527 to the required mode by activating the previously specified setup parameters. The command is ignored and responds with an error value if a measurement is still running or if it is tried to set the mode to MODE_MCS when the gating mode 'sort by time' (see CMD_SET_GATING) is set.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		mode		0				end flag		
Byte string (HEX)	A5	5A	45	00	mode	00	00	00	00	00	B9	9B	

5 Including the overflow (bit 14) and the gate input (bit 15).

6 Note, there are hardware modifications without offset DAC and without hardware-based coarse gain. In such a case, the general mode 3 works only properly if the input signal is adjusted by default for this mode.

7 The time stamp recorders are no standard components of all firmware versions. The availability of the time stamp recorders is indicated by the corresponding flag within the parameter "MCA features" (byte offset 8) returned by CMD_QUERY_STATE527.

8 See the remarks on CMD_SET_AHRC_PARAM for more information.

9 The list mode 4 is planned in future firmware versions.

10 Since firmware version 16.00. The list mode 5 is no standard component of all firmware versions. The availability of it is indicated by the corresponding flag within the parameter "MCA features" (byte offset 8) returned by CMD_QUERY_STATE527.

MCA Acquire Commands:

Command name	CMD_START										
Compatibility	Compatible to the MCA166 command.										
Execution right	Necessary										
Description	<p>The MCA527 distinguishes different general modes (see CMD_SET_GENERAL_MODE). The command behaves accordingly to the general mode.</p> <p>MCA: The data acquisition is started depending on the flags. In repeat modes, the previous data are always cleared and the passed start time is used for the first sweep and is incremented internally by firmware once a second to be used for the following sweeps.</p> <p>Flags:</p> <ul style="list-style-type: none"> 0 = Continues the previous data acquisition. The start time is ignored. 1 = All previous data are cleared and a new data acquisition is started. 2 = Repeat mode 1¹¹ (MCA/MCS) 3 = Repeat mode 2¹² (MCA) 4 = Repeat mode 3¹³ (MCA) 5 = Repeat mode 4¹⁴ (MCS) 6 = Repeat mode 5¹⁵ (MCA/MCS) 7 = Repeat mode 6¹⁶ (MCA) 8 = Repeat mode 7¹⁷ (MCS) <p>Bit 15: trigger1: 0 = inactive, 1 = active^{18 19}</p> <p>Bit 14: trigger2: 0 = inactive, 1 = active</p> <p>Bit 13: trigger3: 0 = inactive, 1 = active</p> <p>Bit 12: repeated triggering²⁰: 0 = inactive, 1 = active</p> <p>Start time: Seconds since December 31, 1969, 16:00:00 GMT²¹</p> <p>Other general modes: The command starts the data acquisition if it is not already running. The flags are ignored. Except for the oscilloscope mode, the start time is taken over.</p>										
Format	integer	integer	integer	integer	integer	integer	integer	integer	integer	integer	integer
Parameter	preamble	command	flags	start time	end flag						
Byte string (HEX)	A5	5A	42	00	flags _l	flags _h	st _l	st _h	B9 9B
Remarks	Repeat modes are only allowed in MCS mode or in MCA mode with measurement stop condition equal to PRESET_REAL or PRESET_REAL_MILLISECONDS (see CMD_SET_PRESETS). If the conditions are not kept, the command is ignored and responded with an error value										

11 Measurement will be stopped if buffer overruns. In MCS mode a differential amplitude spectrum per sweep is collected.

12 Measurement will be suspended if buffer overruns, and will be resumed, after the buffer is read out.

13 MCA166: Buffer will be overwritten, even if not read out.

MCA527: Buffer will be overwritten, if it is unlocked, otherwise the MCA will be suspended.

14 MCS Repeat Mode with one integral amplitude spectrum for all MCS sweeps. (MCA166: not for MCS Input TTL)

15 Similar to repeat mode 1, but the data are saved on the intern microSD card instead of the buffer.

16 Similar to repeat mode 2, but the data are saved on the intern microSD card instead of the buffer.

17 Similar to repeat mode 4, but the data are saved on the intern microSD card instead of the buffer.

18 The measurement can be triggered by external signals on the extension port pins. The extension port is available at the full, OEM and micro version of the MCA527. The pins have to be configured with CMD_SET_EXTENSION_PORT and CMD_SET_EXTENSION_POLARITY. The valid options for the extension port pins are 'Trigger' and 'Input'. If the extension port pin is misconfigured or even missing, the corresponding bits are ignored.

19 The trigger bits are available since firmware version 17.00.

20 In firmware repeat mode 2 and 6, each sub-measurement is discretely triggered if this bit is set.

21 This parameter is usually used in this way, but it can be also used in any other way. The start time based on this parameter is returned by CMD_QUERY_STATE, byte offset 100.

Command name	CMD_START_NEW_SWEEP											
Compatibility	New MCA527 command (since firmware version 16.00).											
Execution right	Necessary											
Description	<p>The command stops the current sweep, starts a new sweep without any time delay and returns the measuring data of the just stopped sweep. The command is an alternative to the repeat mode, which basically does the same at preset intervals.</p> <p>The command requires the following conditions: general mode = 'MCA', mode = 'MCA', automatic stop condition (preset) = 'none' and the measurement must be run. If any of the conditions is not met, the command is ignored and responded with an error value.</p> <p>It is essential to check the returned value 'Buffer state', because if the buffer is still occupied²² by previous measuring data, it can not yet be used for the next one. If this happens, the command returns without stopping the current and starting a new sweep. In this case, the command must be repeated.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		0		0				end flag	
Byte string (HEX)	A5	5A	39	01	00	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	unused						2 bytes					
Byte offset 2	Detected counts						48 bit integer					
Byte offset 8	unused						2 bytes					
Byte offset 10	Counts above the spectrum range						48 bit integer					
Byte offset 16	Start time						unsigned long					
Byte offset 20	Real time [s]						unsigned long					
Byte offset 24	Fractional digits of the real time [msec]						unsigned short					
Byte offset 26	unused						2 bytes					
Byte offset 28	Dead time [ms]						unsigned long					
Byte offset 32	Fast dead time [ms]						unsigned long					
Byte offset 36	PUR counter						unsigned long					
Byte offset 40	Battery current [mA]						unsigned long		At the MCA527Micro this data corresponds to the USB input voltage.			
Byte offset 44	HV primary current [mA]						unsigned long					
Byte offset 48	+12V primary current [mA]						unsigned long					
Byte offset 52	-12V primary current [mA]						unsigned long					
Byte offset 56	+24V primary current [mA]						unsigned long					
Byte offset 60	-24V primary current [mA]						unsigned long					
Byte offset 64	Battery voltage [mV]						unsigned long		At the MCA527Micro this data corresponds to the USB input voltage.			
Byte offset 68	HV [* 1.2 V]						unsigned long					

²² The firmware internally deals with three memory buffers. One buffer is being used for the current measuring data, one buffer is containing the directly previous measuring data and one buffer is being erased to use it for the next measuring data. Occupied means the buffer for the next measuring data has not yet be fully erased.

Command name	CMD_START_NEW_SWEEP (Continuation)		
Result data array			
Byte offset 72	+12V actual value [* 0.0625 V]	unsigned char	
Byte offset 73	-12V actual value [* 0.0625 V]	unsigned char	
Byte offset 74	+24V actual value [* 0.125 V]	unsigned char	
Byte offset 75	-24V actual value [* 0.125 V]	unsigned char	
Byte offset 76	Voltage on SUB-D9 pin3 [* 0.3125 mV]	unsigned short	meaningful only for MCA527 full version
Byte offset 78	Voltage on SUB-D9 pin5 [* 0.3125 mV]	unsigned short	meaningful only for MCA527 full version
Byte offset 80	Charger current [mA]	unsigned long	
Byte offset 84	Extension port counter 1	unsigned long	
Byte offset 88	Extension port counter 2	unsigned long	
Byte offset 92	Extension port counter 3	unsigned long	
Byte offset 96	MCA temperature [* 0.007 812 5 °C]	short	0x8000 = not available
Byte offset 98	Detector temperature [* 0.007 812 5 °C] ²³	short	0x8000 = not available
Byte offset 100	Power module temperature [* 0.007 812 5 °C]	short	0x8000 = not available
Byte offset 102	Additional temperature 1 [* 0.007 812 5 °C] ²⁴	short	0x8000 = not available
Byte offset 104	Additional temperature 2 [* 0.007 812 5 °C] ²⁵	short	0x8000 = not available
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Buffer state	unsigned short	OCCUPIED = 0x2000 OVERRUN = 0x4000 FILLED = 0x8000
Byte offset 116	unused	10 bytes	
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	unused	2 bytes	
Remarks	Unlike the repeat mode, the command does not consider whether the data buffer is locked by CMD_QUERY_SPECTRA, CMD_QUERY_SPECTRA_EX, CMD_QUERY_SPECTRA_EX2 or CMD_QUERY_EXTENSION_RS232_RX.		

²³ Full version: This value comes from the one-wire interface if a corresponding temperature sensor is connected.

Micro and OEM version: The value from an additional external temperature sensor connected to the two-wire interface with the address 1001 0100 is assumed as the detector temperature. This sensor must be a TMP102 (Micro) or LM73 (OEM).

²⁴ Additional external temperature sensor at the two-wire interface with address 1001 0000. The sensor must be a TMP102 (Micro) or LM73 (OEM).

²⁵ Additional external temperature sensor at the two-wire interface with address 1001 0110 (Micro) or 1001 1000 (OEM). The sensor must be a TMP102 (Micro) or LM73 (OEM).

Command name	CMD_STOP											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	In MCA mode the measurement is stopped at the next integer real time, otherwise immediately											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		0		0				end flag	
Byte string (HEX)	A5	5A	43	00	00	00	00	00	00	00	B9	9B

MCA Setup Commands:

Command name	CMD_SET_ADC_RES_DISCR											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the ADC resolution (res: 128, 256 ... 16384), the LLD (Low level discriminator) and the ULD (Upper level discriminator) to the values of its three parameter.</p> <p>The maximum resolution is returned by CMD_QUERY_STATE527, byte offset 56.</p> <p>The LLD must be smaller than the ULD. The maximum ULD is equal ADC resolution minus 1.</p> <p>The command is ignored and responded with an error value if one or more parameter are invalid or a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		res		LLD		ULD		end flag	
Byte string (HEX)	A5	5A	46	00	res _l	res _h	LLD _l	LLD _h	ULD _l	ULD _h	B9	9B

Command name	CMD_SET_PRESETS											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the automatic stop condition (pre) to</p> <p>PRESET_NONE = 0 (val is meaningless)</p> <p>PRESET_REAL = 1</p> <p>PRESET_LIVE = 2 (val ≤ 2 000 000)²⁶</p> <p>PRESET_INT = 3</p> <p>PRESET_AREA = 4</p> <p>PRESET_REAL_MILLISECONDS²⁷ = 5</p> <p>and value (val) of the preset.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		pre		val				end flag	
Byte string (HEX)	A5	5A	48	00	pre _l	pre _h	val _l	val _h	B9	9B
Remarks	<p>Except for PRESET_LIVE²⁶ and PRESET_REAL_MILLISECONDS, the MCA527 stops the measurement always at integer real time.</p> <p>For the list modes 1 to 5 (general modes 3 to 7, see CMD_SET_GENERAL_MODE), only PRESET_REAL is supported. PRESET_LIVE, PRESET_INT and PRESET_AREA are without effect and mean the same like PRESET_NONE.</p>											

²⁶ Up to firmware version 13.03, the measurement was stopped always at integer seconds real time. Since firmware version 13.04, if preset is equal to PRESET_LIVE, the measurement is stopped according to the preset live time and the resulting real time is no longer integer. The fractional digits are returned by CMD_QUERY_STATE527_EX, byte offset 80. Besides, in consequence of the more exact automatic stop, the maximum value for PRESET_LIVE was reduced to 65 535. Since firmware version 18.00, the maximum value for PRESET_LIVE is 2 000 000. This is practicable, but with dead times greater than 53 percent, it can be that the measurement is stopped prematurely.

²⁷ Since firmware version 14.03.

Command name	CMD_SET_ROI											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	The command sets the begin and end of the ROI for the preset integral and area. (LLD ≤ begin < end and LLD < end ≤ ULD)											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		beg		end				end flag	
Byte string (HEX)	A5	5A	49	00	beg _l	beg _h	end _l	end _h	00	00	B9	9B

Command name	CMD_SET_REPEAT											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	The command sets the number (rep: 0 ... 65 535) of sweeps for repetitive measurement. Rep = 0 means infinite repetitions. The command is ignored and responds with an error value if a measurement is still running.											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		rep		0				end flag	
Byte string (HEX)	A5	5A	4A	00	rep _l	rep _h	00	00	00	00	B9	9B

Command name	CMD_SET_MCS_CHANNEL											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	The command sets the number of channels (ch: 1 ... 16 384) for MCS mode. The command is ignored and responds with an error value if a measurement is still running.											
Command syntax												
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		ch		0				end flag	
Byte string (HEX)	A5	5A	63	00	ch _l	ch _h	00	00	00	00	B9	9B

Command name	CMD_SET_TIME_PER_CHANNEL											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	The command sets the dwell time per channel (tpc: 1 ... 65 535) for the MCS mode. The dwell time is tpc * 10 ms. The command is ignored and responds with an error value if a measurement is still running.											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		tpc		0				end flag	
Byte string (HEX)	A5	5A	4B	00	tpc _l	tpc _h	00	00	00	00	B9	9B
Remarks	See CMD_SET_TIME_PER_CHANNEL527 (next command).											

Command name	CMD_SET_TIME_PER_CHANNEL527											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command sets the dwell time per channel (tpc: 1 ... 42 949 672 ²⁸) for the MCS mode. The dwell time is $tpc * 0.1$ ms. The command is ignored and responds with an error value if a measurement is still running.											
Format	integer		integer		long				integer		integer	
Parameter	preamble		command		tpc				0		end flag	
Byte string (HEX)	A5	5A	15	01	tpc _l	tpc _h	00	00	B9	9B
Remarks	This command has been added for setting the dwell time with higher resolution.											

Command name	CMD_SET_GAIN											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	The command sets the amplifier coarse(cg) and fine gain(fg). cg: 2, 5, 10, 20, 50, 100, 200, 500 or 1 000 fg: 5 000 ... 65 000 (corresponds to 0.5 ... 6.5)											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		cg		fg		0		end flag	
Byte string (HEX)	A5	5A	4C	00	cg _l	cg _h	fg _l	fg _h	00	00	B9	9B
Remarks	Not all coarse gain levels are realized by hardware. Some coarse gain levels are realized by firmware. The information that coarse gain levels are really hardware-based is returned by CMD_QUERY_STATE527, byte offset 125.											

Command name	CMD_SET_OFFSET_DAC											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command sets the offset DAC ²⁹ . DAC: 0 ... 16 383											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		dac		0				end flag	
Byte string (HEX)	A5	5A	0A	01	dac _l	dac _h	00	00	00	00	B9	9B

²⁸ As from firmware version 13.04, the upper bound has been reduced in favor of other requirements.

²⁹ There are hardware modifications without offset DAC. In such a case, the command has no effect.

Command name	CMD_SET_INPUT_POLARITY											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the input polarity for the internal amplifier.</p> <p>ip = 0 positive input signals ip = 1 negative input signals</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		ip		0				end flag	
Byte string (HEX)	A5	5A	56	00	ip	00	00	00	00	00	B9	9B

Command name	CMD_SET_MCA_INPUT											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the input to shaping or to direct.</p> <p>ip = 0 input shaping (equivalent to 'input amplifier' of the MCA166) ip = 3 input direct (0 ... +3V, no PUR, obsolete, for compatibility with older applications) ip = 4 input direct (0 ... -3V, no PUR, obsolete, for compatibility with older applications) ip = 5 input direct (polarity according to CMD_SET_INPUT_POLARITY, gain according to CMD_SET_GAIN, no PUR)</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		ip		0				end flag	
Byte string (HEX)	A5	5A	54	00	ip	00	00	00	00	00	B9	9B

Command name	CMD_SET_MCS_INPUT											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the input for the Multi-Channel Scaler.</p> <p>ip = 0 external TTL signals³⁰ ip = 1 internal count rate signal ip = 2 counts only pulses with amplitude between LLD and ULD threshold</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		ip		0				end flag	
Byte string (HEX)	A5	5A	55	00	ip	00	00	00	00	00	B9	9B

³⁰ Note, there are hardware modifications without offset DAC and without hardware-based coarse gain. In such a case, this MCS input mode works only properly if the input signal is adjusted by default for this mode.

Command name	CMD_SET_THRESHOLD											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	This command sets the threshold value (thr: 0 ... 60 percent).											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		thr		0				end flag	
Byte string (HEX)	A5	5A	47	00	thr	00	00	00	00	00	B9	9B
Remarks	See next command.											

Command name	CMD_SET_THRESHOLD_TENTHS											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	This command sets the threshold value (thr: 0 ... 600 * 0.1 percent).											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		thr		0				end flag	
Byte string (HEX)	A5	5A	0D	01	thr _l	thr _h	00	00	00	00	B9	9B
Remarks	This command has been added for setting the threshold with higher resolution.											

Command name	CMD_SET_SHAPING_TIME											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the shaping time (dtc).</p> <p>dtc = 1 shaping time low</p> <p>dtc = 3 shaping time high</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		dtc		0				end flag	
Byte string (HEX)	A5	5A	52	00	dtc	00	00	00	00	00	B9	9B
Remarks	The MCA527 provides more than two shaping times, but in order to keep compatibility with older software, this command has been retained. The command allows furthermore to chose the shaping time from a pair of shaping times. This pair can be set by CMD_SET_SHAPING_TIME_PAIR.											

Command name	CMD_SET_SHAPING_TIME_PAIR											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the shaping time pair.(lst = 1 ... 254 * 0.1 µs, hst = 2 ... 255 * 0.1 µs, lst<hst).</p> <p>The highest allowed shaping time is returned by CMD_QUERY_STATE527, byte offset 121.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		lst		hst		0		end flag	
Byte string (HEX)	A5	5A	0C	01	lst	00	hst	00	00	00	B9	9B
Remarks	See also previous command.											

Command name	CMD_SET_TRIGGER_FILTER											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the trigger filters used for low and high shaping time (tfl = 0 ... 5, tfh = 0 ... 5).</p> <p>0 = (-1; +1) 1 = (-1; 0; +1) 2 = (+1; -2; +1) 3 = (+1; 0; -2; 0; +1) 4 = (4* -1; 12* 0; 4* +1) 5 = (4* +1; 4* 0; 4* -2; 4* 0; 4* +1)</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		tfl		tfh		0		end flag	
Byte string (HEX)	A5	5A	03	01	tfl	00	tfh	00	00	00	B9	9B
Remarks	The trigger filter availability flags ³¹ (see CMD_QUERY_STATE527_EX, byte offset 88) mark the available trigger filters. If a non-available trigger filter is tried to set, the command responds with an error value.											

Command name	CMD_SET_TRIGGER_PARAM											
Compatibility	New MCA527 command (since firmware version 13.00).											
Execution right	Necessary											
Description	<p>param: parameter to be set</p> <p>0 = Trigger level for automatic threshold calculation (see CMD_QUERY_STATE527, 78) 1 = Trigger level for automatic threshold calculation for direct input (see CMD_QUERY_STATE527_EX, 98) 2 = Set trigger threshold (see CMD_QUERY_STATE527, 116)</p> <p>value: new value (for format and allowed range, see indicated data result array)</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long			integer		
Parameter	preamble		command		param		value				end flag	
Byte string (HEX)	A5	5A	06	01	p _l	p _h	value _l	value _h	B9	9B

³¹ Since firmware version 12.00.

Command name	CMD_SET_EVAL_FILTER_TYPE											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the evaluation filter type (eft = 0 or 1)</p> <p>0 = standard filter 1 = LF rejection filter 2 = slow rise filter³²</p> <p>The command is not standardly handled. It is only handled if the flag FEATURES_LF_REJECTION is set within the parameter "MCA features" that is returned by CMD_QUERY_STATE527, byte offset 8, or if the flag FEATURES2_SLOW_RISE is set within the parameter "MCA features (2nd group)" that is returned by CMD_QUERY_STATE527_EX2, byte offset 120.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		eft		0				end flag	
Byte string (HEX)	A5	5A	14	01	eft	00	00	00	00	00	B9	9B

Command name	CMD_SET_FLAT_TOP_TIME											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the flattop times (ftt = 0 ... 255 * 0.1 μs, ftt2 = 0 ... 255 * 0.1 μs, ftt2 \leq ftt).</p> <p>Until firmware version 13.06 the highest allowed flattop time was equal to 50. Since firmware version 13.07 the highest allowed flattop time is returned by CMD_QUERY_STATE527_EX, byte offset 33.</p> <p>The second flattop time has been added in firmware version 16.00. It is used for special optional evaluation routines.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		ftt		ftt2				end flag	
Byte string (HEX)	A5	5A	13	01	ftt	00	ftt2	00	00	00	B9	9B

Command name	CMD_SET_JITTER_CORRECTION											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the jitter correction.</p> <p>jc = 0 turns jitter correction off jc \neq 0 turns jitter correction on</p> <p>The command is not standardly handled. It is only handled if the flag FEATURES_JITTER_CORRECTION is set within the value "MCA features" that is returned by CMD_QUERY_STATE527, byte offset 8.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		jc		0				end flag	
Byte string (HEX)	A5	5A	16	01	jc	00	00	00	00	00	B9	9B

³² Since firmware version 19.00

Command name	CMD_SET_BASELINE_RESTORING											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the baseline restorer.</p> <p>blr = 0 off blr = 1 1/1 blr = 2 1/2 blr = 3 1/4 blr = 4 1/8 blr = 5 1/16 blr = 6 1/32</p> <p>The command is not standardly handled. It is only handled if the flag FEATURES_ADJUSTABLE_BASELINE_RESTORER is set within the value "MCA features" that is returned by CMD_QUERY_STATE527, byte offset 8.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		blr		0				end flag	
Byte string (HEX)	A5	5A	18	01	blr	00	00	00	00	00	B9	9B

Command name	CMD_SET_PUR											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the pile up rejection.</p> <p>pur = 0 turns PUR off pur ≠ 0 turns PUR on</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		pur		0				end flag	
Byte string (HEX)	A5	5A	53	00	pur	00	00	00	00	00	B9	9B

Command name	CMD_SET_MINIMUM_EVENT_DISTANCE											
Compatibility	New MCA527 command (since firmware version 19.03).											
Execution right	Necessary											
Description	<p>This command sets the minimum event distance (0 ... 5000 * 100 nsec, default 0).</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	Preamble		command		med		0				end flag	
Byte string (HEX)	A5	5A	50	00	med _l	med _h	00	00	00	00	B9	9B
Remarks	<p>This parameter is only relevant if the pile up rejection (PUR) is on.</p> <p>There is always a time interval between two events. This means, subsequent events (signal impulses) that occur before the expiration of this time interval are not evaluated. Normally, this time interval is dependent on the shaping time and the flat top time (2 * shaping time plus flat top time). In some cases it can be useful to extend this time interval to improve the accuracy of the measurement.</p>											

Command name	CMD_SET_FAST											
Compatibility	Compatible to the MCA166 command. The command is meaningless for the MCA527. It has only been retained for compatibility with older software											
Execution right	Necessary											
Description	This command sets the fast discriminator threshold (0 ... 2499, default 400).											
Format	integer		integer		integer		long				integer	
Parameter	Preamble		command		fast		0				end flag	
Byte string (HEX)	A5	5A	50	00	fast _l	fast _h	00	00	00	00	B9	9B

Command name	CMD_SET_SLOW											
Compatibility	Compatible to the MCA166 command. The command is meaningless for the MCA527. It has only been retained for compatibility with older software											
Execution right	Necessary											
Description	This command sets the slow discriminator threshold (0 ... 2499, default 400).											
Format	integer		integer		integer		long				integer	
Parameter	Preamble		command		slow		0				end flag	
Byte string (HEX)	A5	5A	51	00	slow _l	slow _h	00	00	00	00	B9	9B

Command name	CMD_SET_MEASURE_PZC											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command performs the Pole Zero Cancellation.</p> <p>pv: 0 ... 2499 PZC control voltage</p> <p>pm = 0 set PCZ only</p> <p>pm > 0 set PZC and measure PZC offset</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		pm		pv		0		end flag	
Byte string (HEX)	A5	5A	58	00	pm _l	pm _h	pv _l	pv _h	00	00	B9	9B
Result data array												
Byte offset 0	unused						106 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						10 bytes					
Byte offset 124	Averaged negative offset of measured input pulses ^{33 34}						short					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	Number of measured pulses						unsigned short					
Byte offset 130	Averaged negative offset of measured input pulses (compliant to the MCA166) ³⁴						short					
Remarks	This command takes at least 800 milliseconds to return, because it runs a measurement of this duration.											

³³ Since firmware version 12.05.

³⁴ The both values at byte offset 124 and 128 stand in principle for the same parameter. However, the value at byte offset 124 is 32 times larger than the value at byte offset 128. The value at byte offset 124 has been added to achieve a higher precision.

Command name	CMD_SET_GATING_TIME_WINDOW_WIDTH											
Compatibility	New MCA527 command (since firmware version 14.02).											
Execution right	Necessary											
Description	<p>The command sets the width of the time windows for the gating mode 'sort by time' (see CMD_SET_GATING).</p> <p>index: 0 ... 7</p> <p>width: 1 ... 4 294 966 289 * 100 nsec³⁷</p> <p> 0xFFFFFFFF = infinite (until the next gating signal)</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		index		width				end flag	
Byte string (HEX)	A5	5A	32	01	index _l	index _h	width _l	width _h	B9	9B

Command name	CMD_SET_GATING_TIME_PER_CHANNEL											
Compatibility	New MCA527 command (since firmware version 16.00).											
Execution right	Necessary											
Description	<p>The command sets the time per channel of the MCS spectrum that is acquired at the gating mode 'sort by time' (see CMD_SET_GATING).</p> <p>Time per channel (tpc): 1 ... 65 535 * 100 nsec³⁷</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		tpc		0				end flag	
Byte string (HEX)	A5	5A	3A	01	tpc _l	tpc _h	0	0	0	0	B9	9B

³⁷ The time of 100 ns refers to the standard ADC sample rate of 10 MHz. See also CMD_QUERY_SYSTEM_DATA, byte offset 130.

MCA Stabilization Commands:

Command name	CMD_SET_STABILISATION											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the peak stabilization.</p> <p>fl: 0 turns stabilization off 1 stabilization to the current centroid within peak ROI 2 stabilization to the current centroid of the highest peak within the spectrum rb+3<fl<re-3 stabilization to channel fl Bit 15 = 0 use normal spectrum Bit 15 = 1 use rejected spectrum (allowed only if gating mode is set to 'sort by state', see CMD_SET_GATING)</p> <p>rb: Peak ROI begin (LLD<= begin < end) re: Peak ROI end (begin < end <= ULD, (end-begin) < 250)</p>											
Command syntax												
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		fl		rb		re		end flag	
Byte string (HEX)	A5	5A	4D	00	fl _l	fl _h	rb _l	rb _h	re _l	re _h	B9	9B

Command name	CMD_SET_STAB_PARAM											
Compatibility	Identical to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the stabilization parameters.</p> <p>st: time interval (1 ... 32 767 sec., default 10 sec.) sa: area (default 25 000)</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		st		sa				end flag	
Byte string (HEX)	A5	5A	67	00	st _l	st _h	sa _l	sa _h	B9	9B

MCA Detector Power Commands:

Command name	CMD_SET_PREAMPLIFIER_POWER											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the preamplifier power (pp).</p> <p>0X80 -24V on 0X40 +24V on 0X20 -12V on 0X10 +12V on 0XF0 all on 0X00 all off</p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		pp		0				end flag	
Byte string (HEX)	A5	5A	4E	00	pp	00	00	00	00	00	B9	9B
Remarks	The Lite version provides no ± 24 V and the OEM and the Micro version provides no preamplifier power at all. The corresponding bits are ignored.											

Command name	CMD_SET_BIAS											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the detector high voltage (hv) and controls the HV inhibit input (i).</p> <p> hv: 0 V ... maximum allowed high voltage (see CMD_QUERY_STATE527, byte offset 64) i = 0 Inhibit off i = 1 "Canberra HPGe mode", HV shut down if inhibit input < 0.5V³⁸ i = 2 "DSG HPGe mode", HV shut down if inhibit input < 0.5V³⁸ i = -1 "Ortec HPGe mode", HV shut down if inhibit input ≥ 5V </p>											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		hv		i				end flag	
Byte string (HEX)	A5	5A	4F	00	h _v _l	h _v _h	i _l	i _h	B9	9B
Remarks	<p>Not all versions of the MCA527 supplies high voltage. For high voltage supply, the MCA527 must contain a power module. The parameter 'MCA features' (see CMD_QUERY_STATE527, byte offset 8) indicates the availability of a power module. If the command is sent to a MCA527 without power module, the command returns with an error.</p> <p>If the high voltage exceeds the 'maximum allowed high voltage' (see CMD_QUERY_STATE527, byte offset 64), the command returns with an error.</p> <p>Only the full version of the MCA527 provides HV inhibit input. All other MCA527s ignore this parameter.</p> <p>If the connected detector supplies detector information, the MCA527 compares the polarity of the detector with that of the power module. If the polarities are different, all settings are ignored.</p>											

Command name	CMD_SET_PIN5_CURRENT_SOURCE											
Compatibility	New MCA527 command											
Execution right	Necessary											
Description	The command switches the current source (cs) on SUB-D9 pin5 on (= 1) or off (= 0).											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		cs		0				end flag	
Byte string (HEX)	A5	5A	19	01	cs	00	00	00	00	00	B9	9B
Remarks	The SUB-D9 pin5 is supported by the full version and partially by OEM version.											

³⁸ Mode 1 and 2 are identical. The difference is made by reasons of legacy.

MCA Data Setup Commands:

Command name	CMD_SET_TDF											
Compatibility	Compatible to the MCA166 command. The command is meaningless for the MCA527. It has only been retained for compatibility with older software											
Execution right	Necessary											
Description	The command does nothing. It has only been retained for compatibility with older software											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		tdf		0				end flag	
Byte string (HEX)	A5	5A	61	00	tdf _l	tdf _h	0	0	0	0	B9	9B
Remarks	The command is meaningless for the current firmware version. Possibly, future firmware will use the parameter again.											

Command name	CMD_SET_UF6_ROIS											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command sets the begin and the end of a ROI used by the other UF6 commands. The name of the command refers to its original usage.</p> <p>r: ROI number (1, 2 or 3)</p> <p>b: ROI begin</p> <p>e: ROI end</p> <p><i>Up to firmware version 14.01:</i> $b < e < \text{max. channels number}$, $(e - b) < 512$.</p> <p><i>Since firmware version 14.02:</i> $b < e < \text{max. channels number}$</p> <p>If $b = 0$ and $e = 0$, the corresponding ROI is reset to "not used".</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		r		b		e		end flag	
Byte string (HEX)	A5	5A	64	00	r	00	b _l	b _h	e _l	e _h	B9	9B

Command name	CMD_SET_USER_DATA											
Compatibility	Compatible to the MCA166 command.											
Execution right	Necessary											
Description	<p>The command stores any 32 bit value (val) in the MCA memory (256 entries).</p> <p>e: 0 ... 255 entry number</p>											
Format	integer		integer		integer		32 bit				integer	
Parameter	preamble		command		e		val				end flag	
Byte string (HEX)	A5	5A	57	00	e	00	B9	9B
Remarks	See also document "Use of MCA User Data Memory by Specific Applications".											

Command name	CMD_SET_TIME											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command sets the time (t) on the internal clock. Bit 31 ... 17: days since January 1, 2008 Bit 16 ... 12: hours (0 ... 23) Bit 11 ... 6: minutes (0 ... 59) Bit 5 ... 0: seconds (0 ... 59)											
Format	integer		integer		32 bit				integer		integer	
Parameter	preamble		command		t				0		end flag	
Byte string (HEX)	A5	5A	04	01	t _l	t _h	00	00	B9	9B

Command name	CMD_SET_IP_ADDRESS											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command allows to set a customized IP address. If the IP address is set to 0.0.0.0, the MCA is instructed to obtain the IP address from a DHCP server or if not available, to use Zero Configuration Networking (also named Automatic Private IP Addressing).											
Format	integer		integer		char	char	char	char	integer		integer	
Parameter	preamble		command		ip1	ip2	ip3	ip4	0		end flag	
Byte string (HEX)	A5	5A	0B	01	ip1	ip2	ip3	ip4	00	00	B9	9B

Command name	CMD_SET_COMMON_MEMORY_FILL_STOP											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command sets the fill stop for the common memory. The MCA acquires data until the preset number of bytes has been written. The common memory is used by the following general modes: 1 = Transient recorder (records ADC raw data) 3 = Time stamp recorder (records the timestamps of level triggered signals) 4 = Time stamp recorder (records the timestamps of edge triggered signals) 5 = Time stamp recorder (AHRC = analog high rate counting) stop: 0 ... common memory size (see CMD_QUERY_STATE527_EX)											
Format	integer		integer		long				integer		integer	
Parameter	preamble		command		stop				0		end flag	
Byte string (HEX)	A5	5A	17	01	stop _l	stop _h	00	00	B9	9B
Remarks	For the time stamp recorders, this command is not the only way to preset an automatic stop condition. This can also be done with the command CMD_SET_PRESETS.											

Command name	CMD_SET_TTL_LEVELS											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command allows to change the low level (ll) and the high level (hl) for TTL input signals. The low level must be lower than the high level. The default levels are 0.8V and 2.0V, which are the standard levels for TTL input signals.</p> <p>Micro version³⁹: low level = 6 ... 23 * 0.1V, high level = 7 ... 24 * 0.1V</p> <p>Other versions: low level = 1 ... 99 * 0.1V, high level = 2 ... 100 * 0.1V</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		ll		hl		0		end flag	
Byte string (HEX)	A5	5A	27	01	ll	00	hl	00	00	00	B9	9B

Command name	CMD_SET_OSCI_TRIGGER											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command allows to set source index (s), resolution index (r), threshold (t) and position (p) for the oscilloscope mode.</p> <p>s: 0 ... 4</p> <p>r: -5 ... +13</p> <p>t: 0 ... 16 383</p> <p>p: 0 ... 499</p> <p>The oscilloscope mode is described in document: "MCA527 Oscilloscope Mode".</p>											
Format	integer		integer		char	char	integer		integer		integer	
Parameter	preamble		command		s	r	t		p		end flag	
Byte string (HEX)	A5	5A	11	01	s	r	t _i	t _h	p _i	p _h	B9	9B

Command name	CMD_SET_CORE_CLOCK											
Compatibility	New MCA527 command (since firmware version 13.04).											
Execution right	Necessary											
Description	<p>The command allows to set the core clock of the MCA527 processor.</p> <p>Clk: (1 ... 6) * 100 MHz</p> <p>Use a value between the minimally recommended and the maximally allowed core clock (see CMD_QUERY_SYSTEM_DATA, byte offset 124 and 125)⁴⁰.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		clk		0		0		end flag	
Byte string (HEX)	A5	5A	2D	01	ckl _i	00	00	00	00	00	B9	9B
Remarks	The default core clock is sufficient in most cases. The change of the core clock is only necessary in exceptional cases. Note, a higher core clock consumes more power.											

³⁹ Since firmware version 14.05, the command considered the special characteristic of the micro version. If pin AIN- and pin VCM are tied together, a voltage from 0.5 to 2.5V can be applied between pin AIN+ and pin GND.

⁴⁰ The minimally recommended core clock and the maximally allowed core clock were added in firmware version 14.06 because of the growing number of hardware modifications.

Command name	CMD_SET_AHRC_PARAM											
Compatibility	New MCA527 command (since firmware version 14.00).											
Execution right	Necessary											
Description	<p>The command allows to set the AHRC parameters.</p> <p>param: parameter to be set</p> <p>-1 = AHRC trigger threshold (allowed range = 0 ... 65 535⁴¹)</p> <p>0 ... 9 = AHRC bin width [0 ... 9] (allowed range = 1 ... 2 147 483 647⁴¹)</p> <p>value: new value corresponding to the allowed range</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		long			integer		
Parameter	preamble		command		param		value			end flag		
Byte string (HEX)	A5	5A	30	01	p _l	p _h	value _l	value _h	B9	9B
Remarks	<p>AHRC (Analog High Rate Counting) is a method which is intended for measuring arrangements with several detectors connected in parallel where temporally superposed events are possible.</p> <p>The events are detected with a fixed threshold. An event is recorded when the signal curve exceeds the threshold. From this point on, the differences between the current ADC value and the baseline are summed up until the signal curve falls below the threshold again. This sum is equivalent to the area under the signal curve. Assuming that there is a relation between the area and the number of events, the area is evaluated for detecting potential multiple events.</p> <p>The whole range is subdivided in bins. Bin[0] represents the signals those no valid event is assigned. Bin[1 ... 9] represent signals with the corresponding number of events. In practice, all bins except bin[0] are set to the same width.</p> <p>In order to find out the trigger threshold and the bin widths, an AHRC histogram has to be acquired with CMD_QUERY_AHRC_HISTOGRAM. At first, an applicable trigger threshold has to be determined. If the default value for the trigger threshold is inapplicable, the histogram routine is repeated with various values for the trigger threshold as long as an applicable value is found. If a proper histogram could be acquired, the bin widths can be set according to the visible peaks within the histogram.</p>											

41 The given intervals for the parameters only prevent a firmware hangup. They do not guarantee a meaningful result.

MCA Extension Port Commands:

Command name	CMD_SET_EXTENSION_PORT											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command configures the parts of the extension port. It is only available if the MCA527 version supports the extension port (see "MCA features", CMD_QUERY_STATE527, byte offset 8) otherwise the command will return "not handled".</p> <p>The extension port consists of up to six configurable parts. The availability of the parts is depending on the MCA527 version. It is returned by CMD_QUERY_STATE527_EX, byte offset 30.</p> <p>The command accepts each combination of the following settings with one exception, part A cannot be configured at once with part B and/or part C as RS232 interface.</p> <p>Part A: 0 = EXT_PORT_OFF 4 = EXT_PORT_RS232 5 = EXT_PORT_RS232_BUFFER⁴²</p> <p>Part B and D: 0 = EXT_PORT_OFF 1 = EXT_PORT_PULSER_COMMON_START⁴³ 2 = EXT_PORT_PULSER_SEPARATE_START⁴⁴ 3 = EXT_PORT_OUTPUT 4 = EXT_PORT_RS232 (Part B only) 4 = EXT_PORT_LOOP_THROUGH (Part B only)⁴⁵</p> <p>Part C and E: 0 = EXT_PORT_OFF 1 = EXT_PORT_COUNTER 2 = EXT_PORT_TRIGGER 3 = EXT_PORT_INPUT 4 = EXT_PORT_RS232 (Part C only) 5 = EXT_PORT_RS232_BUFFER (Part C only)</p> <p>Part F: 0 = EXT_PORT_OFF</p> <p> <i>Full version, OEM version:</i> 1 = EXT_PORT_ON⁴⁶ 2 = EXT_PORT_ON_AT_START_UP⁴⁷</p> <p> <i>Micro version:</i> 6 = EXT_PORT_PART_F_PULSER_COMMON_START 7 = EXT_PORT_PART_F_PULSER_SEPARATE_START 8 = EXT_PORT_PART_F_OUTPUT 9 = EXT_PORT_PART_F_COUNTER 10 = EXT_PORT_PART_F_TRIGGER 11 = EXT_PORT_PART_F_INPUT</p>											
Format	integer		integer		char	char	char	char	char	char	integer	
Parameter	preamble		command		a	b	c	d	e	f	end flag	
Byte string (HEX)	A5	5A	1A	01	a	b	c	d	e	f	B9	9B

⁴² The last 1024 data bytes that have been received up to the measurement stop are stored in the buffer.



⁴³ In this mode the pulsers are started and stopped in common with the measurement but it is still possible to start with CMD_START_EXTENSION_PULSER and to stop with CMD_STOP_EXTENSION_PULSER.

⁴⁴ In this mode the pulsers can only be started with CMD_START_EXTENSION_PULSER and stopped with CMD_STOP_EXTENSION_PULSER.

⁴⁵ There are special hardware configurations that allow to loop through the signal from an input pin (part C or E) to this output pin. This feature replaces however the possibility to use this part for RS232 (TX).

⁴⁶ The power output remains turned on as long as the MCA527 remains turned on or until it is turned off by this command.

⁴⁷ The power output will be automatically turned on at power-up of the MCA527.

Command name	CMD_SET_EXTENSION_PORT (Continuation)		
Remarks	<p>The parts of the extension port are attached to the following pins.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Full version</p>  </div> <div style="text-align: center;"> <p>OEM version</p>  </div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p>Part A: pin 1</p> <p>pin 2</p> <p>Part B: pin 4</p> <p>Part C: pin 5</p> <p>Part D: pin 7</p> <p>Part E: pin 6</p> <p>Part F: pin 8</p> </div> <div style="width: 30%;"> <p>pin 3</p> <p>pin 7</p> <p>pin 19</p> <p>pin 21</p> <p>pin 22</p> <p>pin 25</p> <p>pin 26</p> </div> <div style="width: 35%;"> <p>RS232 RX</p> <p>RS232 TX</p> <p>RS232 TX (TTL), pulser2 or output2</p> <p>RS232 RX (TTL), counter2, trigger2 or input2</p> <p>pulser1 or output1</p> <p>counter1, trigger1 or input1</p> <p>5V / 100mA power output</p> </div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p>Micro version</p> <p>Part A: pin X4:RxD</p> <p>pin X4:TxD</p> <p>Part B: <i>not connected</i></p> <p>Part C: <i>not connected</i></p> <p>Part D: <i>not connected</i></p> <p>Part E: <i>not connected</i></p> <p>Part F: pin X4:GPIO</p> </div> <div style="width: 30%;"> <p>MicroE version</p> <p>pin X4:RxD</p> <p>pin X4:TxD</p> <p>pin X3:OUT1</p> <p>pin X3:IN1</p> <p>pin X3:OUT2</p> <p>pin X9:IN2</p> <p>pin X4:GPIO</p> </div> <div style="width: 35%;"> <p>RS232 RX (TTL)</p> <p>RS232 TX (TTL)</p> <p>pulser2 or output2⁴⁸</p> <p>counter2, trigger2 or input2⁴⁸</p> <p>pulser1 or output1⁴⁸</p> <p>counter1, trigger1 or input1⁴⁸</p> <p>pulser3, output3, counter3, trigger3 or input3</p> </div> </div> <p>At the Micro and MicroE version, the parts must be declared as available with the aid of the MCA-527 Basic State Configurator. The program can be downloaded from our software download page.</p>		

Command name	CMD_SET_EXTENSION_POLARITY											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the polarity (pol) for the parts (part) of the extension port.</p> <p>part: 1 = part B</p> <p>2 = part C</p> <p>3 = part D</p> <p>4 = part E</p> <p>5 = part F⁴⁹</p> <p>pol: 0 = positive or rising edge</p> <p>1 = negative or falling edge</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		part		pol		0		end flag	
Byte string (HEX)	A5	5A	1B	01	part	00	pol	00	00	00	B9	9B

⁴⁸ Attention! There is a confusion between hardware and firmware naming.

⁴⁹ Since firmware version 15.06. Micro version only.

Command name	CMD_SET_EXTENSION_PULSER_PERIOD											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the pulser period (p) for the parts (part) of the extension port.</p> <p>part: 1 = part B (pulser2) 3 = part D (pulser1) 5 = part F (pulser3)⁵⁰</p> <p>p: The pulser period must be larger than the pulser width (see next command). If the parameter does not meet this condition, the command will return "invalid parameter".</p> <p> Pulser 1 and 3: 2 ... 4 294 967 295 * 10 ns</p> <p> Pulser 2⁵¹: 2 ... 4 294 967 * 10 µs</p>											
Format	integer		integer		integer		long			integer		
Parameter	preamble		command		part		p			end flag		
Byte string (HEX)	A5	5A	1C	01	part	00	p _l	p _h	B9	9B

Command name	CMD_SET_EXTENSION_PULSER_WIDTH											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command sets the pulser width (w) for the parts (part) of the extension port.</p> <p>part: 1 = part B (pulser2) 3 = part D (pulser1) 5 = part F (pulser3)⁵⁰</p> <p>w: The pulser width must be smaller than the pulser period (see previous command). If the parameter does not meet this condition, the command will return "invalid parameter".</p> <p> Pulser 1 and 3: 1 ... 4 294 967 294 * 10 ns</p> <p> Pulser 2⁵¹: 1 ... 4 294 966 * 10 µs</p>											
Format	integer		integer		integer		long			integer		
Parameter	preamble		command		part		w			end flag		
Byte string (HEX)	A5	5A	1D	01	part	00	w _l	w _h	B9	9B

⁵⁰ Since firmware version 15.06. Micro version only.

⁵¹ The pulsers work differently. Pulser 1 and 3 works very quickly and exactly because it is realized in hardware. Pulser 2, however, is realized in firmware, wherefore it is less quickly and exactly, and it occupies additional system resources. For this reasons pulser 1 and 3 should be preferred.

Command name	CMD_SET_EXTENSION_RS232											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command configures the RS232 interface of the extension port.</p> <p>div: 0x0001 ... 0xFFFF (baud rate = 6 250 000 / div, see predefined constants in mca_comm.h)</p> <p>flags: bits 1, 0: 00 5-bit word 01 6-bit word 10 7-bit word 11 8-bit word</p> <p> bit 2: 0 1 stop bit 1 2 stop bits for non-5-bit word length or 1½ stop bits for 5-bit word length</p> <p> bit 3: 0 parity not transmitted or checked 1 transmit and check parity</p> <p> bit 4: 0 Odd parity 1 Even parity</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		div		flags		0		end flag	
Byte string (HEX)	A5	5A	1E	01	div _l	div _h	flags	00	00	00	B9	9B

Command name	CMD_CLEAR_EXTENSION_RS232_TX											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command clears all bytes which has been written to the RS232 transfer buffer.											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		0		0				end flag	
Byte string (HEX)	A5	5A	1F	01	00	00	00	00	00	00	B9	9B

Command name	CMD_WRITE_EXTENSION_RS232_TX_ASCII											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	<p>The command is intended for transferring strings via the RS232 interface. Each call writes up to 6 characters to the end of the RS232 transfer buffer. A zero character terminates the string and starts the transfer. The transfer buffer is 300 bytes long. If it is full, the transfer is started automatically.</p> <p>Before starting a new string transfer, it is recommendable to check the RS232 transfer buffer byte count (see CMD_QUERY_STATE527_EX, byte offset 80). If the transfer buffer is not empty, it can be cleared with CMD_CLEAR_EXTENSION_RS232_TX. It is also possible to clear the transfer buffer preventively without checking the byte count.</p>											
Format	integer		integer		char	char	char	char	char	char	integer	
Parameter	preamble		command		c1	c2	c3	c4	c5	c6	end flag	
Byte string (HEX)	A5	5A	20	01	c1	c2	c3	c4	c5	c6	B9	9B

Command name	CMD_WRITE_EXTENSION_RS232_TX_BINARY												
Compatibility	New MCA527 command.												
Execution right	Necessary												
Description	<p>The command is intended for transferring bytes via the RS232 interface. Each call writes up to 4 bytes to the end of the RS232 transfer buffer.</p> <p>flags: bits 2...0: 000 write 0 bytes 001 write 1 byte 010 write 2 bytes 011 write 3 bytes 100 write 4 bytes</p> <p> bit 7: 1 = start transfer</p> <p>The transfer buffer is 300 bytes long. If it overruns, it will be cleared and the command will be return "invalid parameter".</p> <p>Before starting to fill the transfer buffer with new data, it is recommendable to check the RS232 transfer buffer byte count (see CMD_QUERY_STATE527_EX, byte offset 80). If the transfer buffer is not empty, it can be cleared with CMD_CLEAR_EXTENSION_RS232_TX. It is also possible to clear the transfer buffer preventively without checking the byte count.</p>												
Format	integer		integer		integer		byte	byte	byte	byte	integer		
Parameter	preamble		command		flags		b1	b2	b3	b4	end flag		
Byte string (HEX)	A5	5A	21	01	flags	00	b1	b2	b3	b4	B9	9B	

Command name	CMD_START_EXTENSION_PULSER												
Compatibility	New MCA527 command.												
Execution right	Necessary												
Description	<p>The command starts the selected pulser. The command will only be executed successfully if the corresponding parts have been correctly configured (see CMD_SET_EXTENSION_PORT).</p> <p>part: 1 = part B (pulser2) 3 = part D (pulser1) 5 = part F (pulser3)⁵² 7 = part B (pulser2) and part D (pulser1) 9 = part B (pulser2) and part F (pulser3) 11 = part D (pulser1) and part F (pulser3) 255 = all parts</p>												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		part		0				end flag		
Byte string (HEX)	A5	5A	22	01	part	00	00	00	00	00	B9	9B	

Command name	CMD_STOP_EXTENSION_PULSER												
Compatibility	New MCA527 command.												
Execution right	Necessary												
Description	<p>The command stops the selected pulser. The command will only be executed successfully if the corresponding parts have been correctly configured (see CMD_SET_EXTENSION_PORT).</p> <p>part: see CMD_START_EXTENSION_PULSER</p>												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		part		0				end flag		
Byte string (HEX)	A5	5A	23	01	part	00	00	00	00	00	B9	9B	

⁵² Since firmware version 15.06. Micro version only.

Command name	CMD_SET_EXTENSION_OUTPUT												
Compatibility	New MCA527 command.												
Execution right	Necessary												
Description	<p>The command sets the selected output. The command will only be executed successfully if the corresponding parts have been correctly configured (see CMD_SET_EXTENSION_PORT).</p> <p>part: 1 = part B (output2) 3 = part D (output1) 5 = part F (output3)⁵³ 7 = part B (output2) and part D (output1) 9 = part B (output2) and part F (output3) 11 = part D (output1) and part F (output3) 255 = all parts</p> <p>o1: 0 = off, ≠0 = on o2: 0 = off, ≠0 = on o3: 0 = off, ≠0 = on</p>												
Format	integer		integer		integer		byte	byte	byte	byte	integer		
Parameter	preamble		command		part		o1	o3	o2		end flag		
Byte string (HEX)	A5	5A	24	01	part	00	o1	o3	o2	00	B9	9B	

MCA File System Command:

Command name	CMD_WRITE_FILE												
Compatibility	New MCA527 command.												
Execution right	Necessary												
Description	<p>The command writes the current measurement into a file. The file name is created automatically from a consecutive number. Basis for this command is that a microSD card with enough free memory is plugged in.</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>												
Format	integer		integer		integer		integer		integer		integer		
Parameter	preamble		command		0		0		0		end flag		
Byte string (HEX)	A5	5A	28	01	00	00	00	00	00	00	B9	9B	
Remarks	<p>Call CMD_QUERY_STATE527_EX to get the needed and the free microSD memory size. The command returns immediately., so CMD_QUERY_STATE527_EX has to be called again to get the state and the result of the file writing process.</p>												

⁵³ Since firmware version 15.06. Micro version only.

MCA Query Commands:

Command name	CMD_QUERY_POWER											
Compatibility	Compatible to the MCA166 command.											
Execution right	Not necessary											
Description	The command reads the power state.											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		0		0				end flag	
Byte string (HEX)	A5	5A	59	00	00	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Battery current [mA]						unsigned long		At the MCA527Micro this data corresponds to the USB input current.			
Byte offset 4	HV primary current [mA]						unsigned long					
Byte offset 8	+12 V primary current [mA]						unsigned long					
Byte offset 12	-12 V primary current [mA]						unsigned long					
Byte offset 16	+24 V primary current [mA]						unsigned long					
Byte offset 20	-24 V primary current [mA]						unsigned long					
Byte offset 24	Battery voltage [mV]						unsigned long		At the MCA527Micro this data corresponds to the USB input voltage.			
Byte offset 28	HV [* 1.2 V]						unsigned long					
Byte offset 32	HV state						unsigned long		meaningless for MCA527			
Byte offset 36	+ 12 V actual value [* 0.0625 V]						unsigned char					
Byte offset 37	- 12 V actual value [* 0.0625 V]						unsigned char					
Byte offset 38	+ 24 V actual value [* 0.125 V]						unsigned char					
Byte offset 39	- 24 V actual value [* 0.125 V]						unsigned char					
Byte offset 40	Current high voltage [V]						unsigned long					
Byte offset 44	Voltage on SUB-D9 pin3 [* 0.3125 mV]						unsigned short		meaningful only for MCA527 full version			
Byte offset 46	Voltage on SUB-D9 pin5 [* 0.3125 mV]						unsigned short		meaningful only for MCA527 full version			
Byte offset 48	Power switches						unsigned long		0X80 -24V ON 0X40 +24V ON 0X20 -12V ON 0X10 +12V ON			
Byte offset 52	Charger current [mA]						unsigned long					
Byte offset 56	Current source value on SUB-D9 pin5 [* 0.1 µA]						unsigned short		meaningful only for MCA527 full version			
Byte offset 58	Current source state on SUB-D9 pin5 (0 = off, 1 = on)						unsigned short		meaningful only for MCA527 full version			
Byte offset 60	Input resistance on SUB-D9 pin5 [kΩ]						unsigned short		meaningful only for MCA527 full version			

Command name	CMD_QUERY_POWER (1 st Continuation)		
Result data array			
Byte offset 62	ADC correction offset on SUB-D9 pin5 [LSB]	char	meaningful only for MCA527 full version
Byte offset 63	Gain correction factor on SUB-D9 pin5 (factor = 0.001 * value + 1)	char	meaningful only for MCA527 full version
Byte offset 64	Battery current [mA] of the previous sweep ⁵⁴	unsigned long	At the MCA527Micro this data corresponds to the USB input voltage.
Byte offset 68	HV primary current [mA] of the previous sweep	unsigned long	
Byte offset 72	+12V primary current [mA] of the previous sweep	unsigned long	
Byte offset 76	-12V primary current [mA] of the previous sweep	unsigned long	
Byte offset 80	+24V primary current [mA] of the previous sweep	unsigned long	
Byte offset 84	-24V primary current [mA] of the previous sweep	unsigned long	
Byte offset 88	Battery voltage [mV] of the previous sweep	unsigned long	At the MCA527Micro this data corresponds to the USB input voltage.
Byte offset 92	HV [* 1.2 V] of the previous sweep	unsigned long	
Byte offset 96	ADC correction offset on SUB-D9 pin3 [LSB]	char	meaningful only for MCA527 full version
Byte offset 97	Gain correction factor on SUB-D9 pin3 (factor = 0.001 * value + 1)	char	meaningful only for MCA527 full version
Byte offset 98	HV control voltage [mV] ⁵⁵	unsigned short	meaningful for MCA527Micro with power module firmware version ≥ 0.5
Byte offset 100	+12V actual value [* 0.0625 V] of the previous sweep	unsigned char	
Byte offset 101	-12V actual value [* 0.0625 V] of the previous sweep	unsigned char	
Byte offset 102	+24V actual value [* 0.125 V] of the previous sweep	unsigned char	
Byte offset 103	-24V actual value [* 0.125 V] of the previous sweep	unsigned char	
Byte offset 104	Voltage on SUB-D9 pin3 [* 0.3125 mV] of the previous sweep	unsigned short	meaningful only for MCA527 full version
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Voltage on SUB-D9 pin5 [* 0.3125 mV] of the previous sweep	unsigned short	meaningful only for MCA527 full version
Byte offset 116	Charger current [mA] of the previous sweep	unsigned long	
Byte offset 120	unused	4 bytes	

⁵⁴ Values which description ends with the string "of the previous sweep" refer either to the previously finished sweep during the repeat mode or to the last stopped measurement.

⁵⁵ Since firmware version 15.02.

Command name	CMD_QUERY_POWER (<i>2nd Continuation</i>)		
Result data array			
Byte offset 124	Power module detector info source (low nibble) ⁵⁵ Power module DAC type (high nibble)	unsigned char	meaningful for MCA527Micro with power module firmware version ≥ 0.5
Byte offset 125	Power module features ⁵⁵	unsigned char	meaningful for MCA527Micro with power module firmware version ≥ 0.5
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	integer value	STATE_READY = 1 STATE_RUN = 2 STATE_SUSPEND = 3 STATE_FINISH = 4 STATE_STOP = 5 STATE_FAIL = 6 STATE_WAIT_FOR_TRIGGER = 7
Byte offset 130	unused	2 bytes	

Command name	CMD_QUERY_SYSTEM_DATA												
Compatibility	Compatible to the MCA166 command.												
Execution right	Not necessary												
Description	The command reads the special MCA data.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	62	00	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	unused						10 bytes						
Byte offset 10	Detected counts						48 bit integer						
Byte offset 16	unused						2 bytes						
Byte offset 18	Counts above the spectrum range ⁵⁶						48 bit integer						
Byte offset 24	unused						2 bytes						
Byte offset 26	Counts above the spectrum range of the previous sweep ^{56 57}						48 bit integer						
Byte offset 32	unused						4 bytes						
Byte offset 36	MMCA on time [s]						unsigned long						
Byte offset 40	Real time [s] of the previous sweep						unsigned long						
Byte offset 44	Dead time [ms] of the previous sweep						unsigned long						
Byte offset 48	Start time of the previous sweep						unsigned long						
Byte offset 52	Fast dead time [ms] of the previous sweep						unsigned long						
Byte offset 56	Elapsed sweeps (repeat mode)						unsigned long						
Byte offset 60	Busy time [ms] of the previous sweep						unsigned long		always 0 at MCA527				
Byte offset 64	Fractional digits ⁵⁸ of the real time [msec] of the previous sweep						unsigned short						
Byte offset 66	unused						8 bytes						
Byte offset 74	Detected counts of the previous sweep						48 bit integer						
Byte offset 80	Counter of stabilization steps						unsigned long						
Byte offset 84	Current stabilization offset ⁵⁹						long						
Byte offset 88	Maximal negative stabilization offset						long						
Byte offset 92	Maximal positive stabilization offset						long						

⁵⁶ Since firmware version 16.00.

⁵⁷ Values which description ends with the string "of the previous sweep" refer either to the previously finished sweep during the repeat mode or to the last stopped measurement.

⁵⁸ Since firmware version 14.03.

⁵⁹ The stabilization offset is the internal fine gain change that is needed to stabilize the peak. Normally, you would have to divide the value by 10 000 to get the float value. But because of compatibility with the MCA166, you have to divide value by 11 142 if it is negative and by 9 104 if it is positive.

Command name	CMD_QUERY_SYSTEM_DATA (<i>Continuation</i>)		
Result data array			
Byte offset 96	Counter of received commands	unsigned long	
Byte offset 100	Counter of unsuccessful commands	unsigned long	
Byte offset 104	unused	2 bytes	
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Buffer state	unsigned short	OCCUPIED = 0x2000 OVERRUN = 0x4000 FILLED = 0x8000
Byte offset 116	Stabilization area preset	unsigned long	
Byte offset 120	Stabilization time preset [sec]	unsigned short	
Byte offset 122	Low shaping time [* 0.1 µsec]	unsigned char	
Byte offset 123	High shaping time [* 0.1 µsec]	unsigned char	
Byte offset 124	Minimum recommended core clock [* 100 MHz] ⁶⁰	unsigned char	
Byte offset 125	Maximum allowed core clock [* 100 MHz] ⁶⁰	unsigned char	
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	ADC sample rate [* 1 kHz] ⁶¹	unsigned short	

⁶⁰ Since firmware version 14.06.

⁶¹ Since firmware version 16.00.

Command name	CMD_QUERY_STATE												
Compatibility	Compatible to the MCA166 command.												
Execution right	Not necessary												
Description	The command reads the state.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	5A	00	00	00	00	00	00	00	00	B9	9B
Result data array													
Byte offset 0	MCA acquire mode						unsigned short		MODE_MCA = 0 MODE_MCS = 1				
Byte offset 2	Preset (automatic stop condition) ⁶²						unsigned short		PRESET_NONE = 0 PRESET_REAL = 1 PRESET_LIVE = 2 PRESET_INT = 3 PRESET_AREA = 4				
Byte offset 4	Preset value						unsigned long						
Byte offset 8	MCA mode: elapsed preset MCS mode: elapsed MCS channels ⁶³						unsigned long						
Byte offset 12	Repeat value						unsigned short						
Byte offset 14	Elapsed sweeps						unsigned short						
Byte offset 16	MCS time per channel [* 10 msec]						unsigned short						
Byte offset 18	Elapsed time per channel [* 10 msec]						unsigned short						
Byte offset 20	Real time [sec]						unsigned long		The fractional digits of the real time are returned by CMD_QUERY_STATE527_EX, byte offset 82.				
Byte offset 24	MCA mode: counts per second MCS mode: counts per channel ⁶⁴						unsigned long						
Byte offset 28	Dead time [msec]						unsigned long						
Byte offset 32	Busy time [msec]						unsigned long		always 0 at MCA527				
Byte offset 36	MCA channels						unsigned short						
Byte offset 38	Threshold [%]						unsigned short		See CMD_QUERY_STATE527 and CMD_SET_THRESHOLD				
Byte offset 40	LLD						unsigned short						
Byte offset 42	ULD						unsigned short						
Byte offset 44	ROI begin (preset integral/area)						unsigned short						
Byte offset 46	ROI end (preset integral/area)						unsigned short						

⁶² For general mode 3 and 4 (see CMD_SET_GENERAL_MODE), only PRESET_REAL is supported, PRESET_LIVE, PRESET_INT and PRESET_AREA are unsupported and mean the same like PRESET_NONE.

⁶³ Since firmware version 13.00.

⁶⁴ Older applications for the MCS mode used the counts per channel to calculate the counts per second. However, this is inexact. For this reason, since firmware version 13.00, the 'counts per second' for both modes are (additionally) returned at byte offset 116. Newer applications for the MCS mode should use this parameter.

Command name	CMD_QUERY_STATE (1 st Continuation)		
Result data array			
Byte offset 48	Amplifier coarse gain	unsigned short	
Byte offset 50	Amplifier fine gain	unsigned short	
Byte offset 52	Slow discriminator value	unsigned short	meaningless for MCA527
Byte offset 54	Fast discriminator value	unsigned short	meaningless for MCA527
Byte offset 56	High voltage [V]	unsigned short	
Byte offset 58	High voltage polarity	unsigned short	0 = positive, 1 = negative
Byte offset 60	Power switches	unsigned short	0X80 -24V ON 0X40 +24V ON 0X20 -12V ON 0X10 +12V ON 0X02 HV ON
Byte offset 62	PZC value	unsigned short	
Byte offset 64	Time offset for PZC and DTC low	unsigned short	meaningless for MCA527
Byte offset 66	Time offset for PZC and DTC high	unsigned short	meaningless for MCA527
Byte offset 68	Stabilization state or channel	unsigned short	
Byte offset 70	Stabilization result	unsigned short	STAB_STARTED = 0 STAB_ACTIVE = 1 STAB_ERROR = 3
Byte offset 72	Stab. ROI begin	unsigned short	
Byte offset 74	Stab. ROI end	unsigned short	
Byte offset 76	ADC input	unsigned short	ADC_SHAPING = 0 ADC_DIRECT_POS = 3 ADC_DIRECT_NEG = 4
Byte offset 78	ADC input polarity	unsigned short	INPUT_POLARITY_POS = 0 INPUT_POLARITY_NEG = 1
Byte offset 80	Shaping time choice ⁶⁵	unsigned short	Low shaping time = 1 High shaping time = 3
Byte offset 82	Pile up rejection (PUR) state	unsigned short	PUR_OFF = 0 PUR_ON = 1
Byte offset 84	MCS input	unsigned short	MCS_INPUT_TTL = 0 MCS_INPUT_RATE = 1 MCS_INPUT_DISCR = 2
Byte offset 86	MCA serial number	unsigned short	
Byte offset 88	MCA hardware version	unsigned short	= 0xFFFF
Byte offset 90	MCA firmware version	unsigned short	= 0xFFFF
Byte offset 92	MCS channels	unsigned short	
Byte offset 94	Last power state	unsigned short	
Byte offset 96	Battery capacity [%]	unsigned short	
Byte offset 98	Battery life time	unsigned short	not supported

⁶⁵ In the MCA-166 User's Manual, this parameter is named DTC. You find therefore this parameter in the source code under this name.

Command name	CMD_QUERY_STATE (2 nd Continuation)		
Result data array			
Byte offset 100	Start time	unsigned long	See CMD_START
Byte offset 104	TDF	unsigned short	always 0 at MCA527
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Buffer state	unsigned short	OCCUPIED = 0x2000 OVERRUN = 0x4000 FILLED = 0x8000
Byte offset 116	Counts per second ⁶⁶	unsigned long	
Byte offset 120	Differential dead time [‰]	unsigned short	
Byte offset 122	HV inhibit mode	short	
Byte offset 124	HV inhibit state	unsigned short	
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	Start flag ⁶⁷	unsigned short	See CMD_START

⁶⁶ Since firmware version 13.00.

⁶⁷ Since firmware version 12.02.

Command name	CMD_QUERY_STATE527												
Compatibility	New MCA527 command.												
Execution right	Not necessary												
Description	The command reads the state.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	01	01	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	MCA hardware version (hexadecimal)						unsigned short		High byte: Low byte:		major version minor version		
Byte offset 2	MCA firmware version (hexadecimal)						unsigned short		High byte: Low byte:		major version minor version		
Byte offset 4	MCA hardware modification						unsigned short		Full version Lite version OEM version Micro version		= 0 = 1 = 2 = 3		
Byte offset 6	MCA firmware modification						unsigned short						
Byte offset 8	MCA features						unsigned long		See remarks at the end of the table (2 nd continuation)				
Byte offset 12	Time on internal clock						32 bits		See CMD_SET_TIME				
Byte offset 16	reserved						4 bytes						
Byte offset 20	Testing phase [sec]						unsigned long		0 0xFFFFFFFF other value		= expired = without = remaining		
Byte offset 24	MCA temperature [* 0.007 812 5 °C]						short		0x8000 = not available				
Byte offset 26	General MCA mode						unsigned short		See CMD_SET_GENERAL_MODE				
Byte offset 28	Discarded cycles						unsigned long		1 discarded cycle = 400 µsec				
Byte offset 32	Core clock [* 100 MHz]						unsigned short						
Byte offset 34	Trigger filter for low shaping time						unsigned char		See CMD_SET_TRIGGER_FILTER				
Byte offset 35	Trigger filter for high shaping time						unsigned char		See CMD_SET_TRIGGER_FILTER				
Byte offset 36	Expander flags						unsigned short						
Byte offset 38	Offset DAC						unsigned short						
Byte offset 40	Detector temperature [* 0.007 812 5 °C] ⁶⁸						short		0x8000 = not available				
Byte offset 42	Power module temperature [* 0.007 812 5 °C]						short		0x8000 = not available				
Byte offset 44	MCA serial number						unsigned short						
Byte offset 46	Am I right holder?						short		0 = no, -1 = yes				
Byte offset 48	Right holder IP address						unsigned char [4]		0.0.0.0 = USB or RS232				
Byte offset 52	Right holder UDP port						unsigned short		0 = USB or RS232				

⁶⁸ *Full version*: The value comes from a temperature sensor that is connected to the one-wire interface.

OEM version: If the board is assembled with a power module, the value comes from a temperature sensor that is connected to the one-wire interface, otherwise the value from an additional external temperature sensor connected to the two-wire interface with the address 1001 0100 is assumed as the detector temperature. This sensor must be a LM73.

Micro version: The value from an additional external temperature sensor connected to the two-wire interface with the address 1001 0100 is assumed as the detector temperature. This sensor must be a TMP102.

Command name	CMD_QUERY_STATE527 (1 st Continuation)		
Result data array			
Byte offset 54	Execution right	short	-1 = not granted 0 = reserved 1 ... 15 = granted
Byte offset 56	Maximum MCA channels provided by this MCA	unsigned short	
Byte offset 58	Power module firmware version	unsigned char	High nibble: major version Low nibble: minor version
Byte offset 59	Power module hardware version	unsigned char	High nibble: major version Low nibble: minor version
Byte offset 60	Power module serial number	unsigned short	
Byte offset 62	Power module ID	unsigned short	Full version = 0 Lite version = 1
Byte offset 64	Maximum allowed high voltage ⁶⁹ [V]	unsigned short	
Byte offset 66	Threshold [* 0.1 %]	unsigned short	See CMD_QUERY_STATE and CMD_SET_THRESHOLD_TENTHS
Byte offset 68	Fast dead time [msec]	unsigned long	
Byte offset 72	Evaluation filter type	unsigned short	
Byte offset 74	Flattop time [* 0.1 µsec]	unsigned short	See CMD_SET_FLAT_TOP_TIME
Byte offset 76	Evaluation filter size	unsigned short	
Byte offset 78	Trigger level for automatic threshold calculation [* 0.0625]	unsigned short	80 ... 1600
Byte offset 80	MCA temperature [* 0.007 812 5 °C] of the previous sweep ⁷⁰	short	0x8000 = not available
Byte offset 82	Detector temperature [* 0.007 812 5 °C] of the previous sweep	short	0x8000 = not available
Byte offset 84	Customized IP address	unsigned char [4]	See CMD_SET_IP_ADDRESS
Byte offset 88	Actual IP address	unsigned char [4]	
Byte offset 92	MCS time per channel [* 0.1 msec]	unsigned long	
Byte offset 96	Elapsed time per channel [* 0.1 msec]	unsigned long	
Byte offset 100	Auto trigger threshold [* 0.000 061 035 156 25] ⁷¹	long	
Byte offset 104	Power module temp. [* 0.007 812 5 °C] of the previous sweep	short	0x8000 = not available
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Jitter correction	unsigned char	0 = off, 1 = on
Byte offset 115	Baseline restoring	unsigned char	0 = off, 1 = 1/1, 2 = 1/2, 3 = 1/4, 4 = 1/8, 5 = 1/16, 6 = 1/32
Byte offset 116	Set trigger threshold [* 0.000 061 035 156 25]	long	0 ... 268 435 455 0 = auto threshold calculation

⁶⁹ The maximum allowed high voltage is determined by the power module, and in some system configurations if the detector is firmly connected, additionally by the maximum high voltage of the detector.

⁷⁰ Values which description ends with the string "of the previous sweep" refer either to the previously finished sweep during the repeat mode or to the last stopped measurement.

⁷¹ Since firmware version 15.00, the auto trigger threshold is also returned for direct input.

Command name	CMD_QUERY_STATE527 (2 nd Continuation)		
Result data array			
Byte offset 120	Input mode	unsigned char	0 = alterable, 1 = fixed
Byte offset 121	Highest allowed shaping time [* 0.1 µsec]	unsigned char	
Byte offset 122	Gating mode	unsigned char	See CMD_SET_GATING
Byte offset 123	Gating signal	unsigned char	See CMD_SET_GATING
Byte offset 124	Gating shift	unsigned char	See CMD_SET_GATING
Byte offset 125	Hardware-based coarse gain levels ⁷² (All other coarse gain levels are realized by the firmware.)	unsigned char	Bit 0: 2, Bit 1: 5, Bit 2: 10, Bit 3: 20, Bit 4: 50, Bit 5: 100 Bit 6: 200, Bit 7: 500
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	Differential fast dead time [%]	unsigned short	
Remarks	<p>The different hardware and firmware versions of the MCA527 support different features. The value "MCA features" (byte offset 8) gives more detailed information about the supported features than the value "MCA hardware modification" (byte offset 4).</p> <p>FEATURES_EXPANDER: The expander is an imperative component of the full, lite and OEM version of the MCA527. If this flag is not set, these devices are defective. The micro version of the MCA527, however, does not contain the expander.</p> <p>FEATURES_INTERN_TEMPERATURE: This flag indicates that the MCA527 supplies the temperature of its circuit board.</p> <p>FEATURES_EXTERN_TEMPERATURE: In Full version, this flag indicates that temperature measuring via 1-wire interface is supplied. The flag does, however, not indicate whether a 1-wire temperature sensor is connected or not. In Micro version, this flag indicates that a temperature sensor with the address 1001 0100 is connected to the two-wire interface. In OEM version, this flag can indicate two different kinds of temperature measuring. If a power module is available, the temperature measuring via 1-wire interface is supplied, otherwise a temperature sensor with the address 1001 0100 is connected to the two-wire interface.</p> <p>FEATURES_MAC_ADDRESS: This flag indicates that the EEPROM that supplies the MAC address for the Ethernet has been detected. A valid MAC address is one of the requirements for connecting the MCA527 via Ethernet.</p> <p>FEATURES_POWER_MODULE: This flag indicates that a power module has been detected. In the full and lite version, the power module is an integral component. If the flag is not set, these devices are defective. In OEM and micro version, the power module is optional. If the flag is not set, the devices either have no power module or they are defective.</p> <p>FEATURES_MSD_CARD: This flag indicates that a micro SD memory card with FAT32 file system has been detected.</p> <p>FEATURES_PMODULE_TEMPERATURE: This flag indicates that the power module supplies the temperature of its circuit board.</p> <p>FEATURES_ANALOG_VOLTAGES: This flag indicates that the MCA527 supports voltage measuring on SUB-D9 pin3 and pin5.</p> <p>FEATURES_GATING_INPUT: This flag indicates that the MCA527 supports gating.</p> <p>FEATURES_EXTENSION_PORT: This flag indicates that the MCA527 supports the extension port. The availability of the single parts is indicated by "Extension port parts availability" (see CMD_QUERY_STATE527_EX, byte offset 30). It is possible to plug a bluetooth module in the extension port. If the MCA527 identifies a bluetooth module, it clears the flag to avoid that other processes try to access to the extension port.</p>		

⁷² Since firmware version 13.05.

Command name	CMD_QUERY_STATE527 (3 rd Continuation)
Remarks	<p>FEATURES_LF_REJECTION: This flag indicates that the MCA527 supports an evaluation filter with low frequency rejection. If this flag is set, the evaluation filter can be chosen with CMD_SET_EVAL_FILTER_TYPE.</p> <p>FEATURES_JITTER_CORRECTION: This flag indicates that the MCA527 supports jitter correction. If not set, the jitter correction cannot be switched on with CMD_SET_JITTER_CORRECTION. The command will return "not handled".</p> <p>FEATURES_ADJUSTABLE_TRIGGER_FILTER: This flag indicates that the MCA527 supports the change between different trigger filters. Since firmware version 12.00, this flag is only set if all four originally existing trigger filters are available. This is due to the compatibility of older programs. Newer programs should always test the value "Trigger filter availability flags" returned from CMD_QUERY_STATE527_EX (byte offset 88) that gives information about the trigger filters that are supported by the current firmware version. If more than one trigger filter is available, the command CMD_SET_TRIGGER_FILTER can be successfully executed otherwise the command will return "not handled".</p> <p>FEATURES_ADJUSTABLE_BASELINE_RESTORER: This flag indicates that the MCA527 supports the change between different settings for the baseline restorer. If not set, only the default setting is available and the command CMD_SET_BASELINE_RESTORING will return "not handled".</p> <p>FEATURES_ADJUSTABLE_COARSE_GAIN: This flag indicates that the MCA527 supports the change between different coarse gain levels. If not set, only the default coarse gain level is available and the command CMD_SET_GAIN will ignore the parameter "coarse gain".</p> <p>FEATURES_USB_CHARGING_DEFAULT_OFF: This flag indicates that the USB charger will not be automatically switched on when the USB cable is plugged in. If the flag is not set, the USB charger will be switched on by default. This flag is only relevant if a power module is existent and the firmware version is higher than 12.01.</p> <p>FEATURES_NO_OFFSET_DAC: This flag indicates that the MCA527 contains no offset DAC. This applies to the micro version. In this case, the MCS TTL input mode and the general mode 3 work only properly if the input signal is adjusted by default for these modes.</p> <p>FEATURES_SDRAM_OK: The MCA527 runs a SDRAM memory test at booting⁷³. If this flag is not set, the device is defective.</p> <p>FEATURES_TIMESTAMP_RECORDER: This flag indicates that the MCA527 supports the time stamp recorders (list modes 1, 2 and 3, respectively general modes 3, 4 and 5).</p> <p>FEATURES_BLUETOOTH: This flag indicates that the MCA527 has detected a Bluetooth module at the extension port.</p> <p>FEATURES_GATING_BY_TIME: This flag indicates that the MCA527 supports the gating mode 'sort by time'.</p> <p>FEATURES_BOOT_PRESETS⁷⁴ ⁷⁵: This flag indicates that the MCA527 is preset at booting with predefined parameters stored within the MCA527 by the manufacturer or a technician.</p> <p>FEATURES_DETECTOR_INFO⁷⁵: This flag indicates that the connected detector supports detector information. However, only the flag FEATURES_DETECTOR_INFO_VALID indicates the validity.</p> <p>FEATURES_DETECTOR_INFO_VALID⁷⁵ ⁷⁴: This flag indicates that the detector information are valid. Some parameters of the detector information are used for presetting the MCA527 at booting.</p> <p>FEATURES_ADDITIONAL_TEMPERATURE1⁷⁶: This flag indicates that an additional external temperature sensor with the corresponding address has been detected at the two-wire interface. The temperature is returned by CMD_QUERY_STATE527_EX2. See there for more information.</p> <p>FEATURES_ADDITIONAL_TEMPERATURE2⁷⁶: See previous flag.</p>

⁷³ Since firmware version 13.05.

⁷⁴ Since firmware version 14.03.

⁷⁵ The flags **FEATURES_BOOT_PRESETS** and **FEATURES_DETECTOR_INFO_VALID** indicate two competing methods for presetting the MCA527 at booting. If both flags are set, the firmware uses the parameters of both sources according to certain rules.

⁷⁶ Since firmware version 15.06. Micro and OEM version only.

Command name	CMD_QUERY_STATE527 (4 th Continuation)
Remarks	<p>FEATURES_FILTER2⁷⁷: This flag indicates that the MCA527 supports a second evaluation filter for special evaluation routines.</p> <p>FEATURES_LISTMODE4⁷⁸: This flag indicates that the MCA527 supports the list mode 4 (general mode 6).</p> <p>FEATURES_LISTMODE5⁷⁷: This flag indicates that the MCA527 supports the list mode 5 (general mode 7).</p> <p>FEATURES_DEBUG_INFO: This flag indicates that the MCA527 supplies additional debug information. The debug information is destined for exclusive use by the MCA527 firmware developer. For this reason it is not described more detailed.</p> <p>Decoding:</p> <pre> #define FEATURES_EXPANDER 0x00000001 #define FEATURES_INTERN_TEMPERATURE 0x00000002 #define FEATURES_EXTERN_TEMPERATURE 0x00000004 #define FEATURES_MAC_ADDRESS 0x00000008 #define FEATURES_POWER_MODULE 0x00000010 #define FEATURES_MSD_CARD 0x00000020 #define FEATURES_PMODULE_TEMPERATURE 0x00000040 #define FEATURES_ANALOG_VOLTAGES 0x00000080 #define FEATURES_GATING_INPUT 0x00000100 #define FEATURES_EXTENSION_PORT 0x00000200 #define FEATURES_LF_REJECTION 0x00000400 #define FEATURES_JITTER_CORRECTION 0x00000800 #define FEATURES_ADJUSTABLE_TRIGGER_FILTER 0x00001000 #define FEATURES_ADJUSTABLE_BASELINE_RESTORER 0x00002000 #define FEATURES_ADJUSTABLE_COARSE_GAIN 0x00004000 #define FEATURES_USB_RS232 0x00008000 #define FEATURES_USB_CHARGING_DEFAULT_OFF 0x00010000 #define FEATURES_NO_OFFSET_DAC 0x00020000 #define FEATURES_SDRAM_OK 0x00040000 #define FEATURES_TIMESTAMP_RECORDERS 0x00080000 #define FEATURES_BLUETOOTH 0x00100000 #define FEATURES_GATING_BY_TIME 0x00200000 #define FEATURES_BOOT_PRESETS 0x00400000 #define FEATURES_DETECTOR_INFO 0x00800000 #define FEATURES_DETECTOR_INFO_VALID 0x01000000 #define FEATURES_RS485_BUS 0x02000000 #define FEATURES_ADDITIONAL_TEMPERATURE1 0x04000000 #define FEATURES_ADDITIONAL_TEMPERATURE2 0x08000000 #define FEATURES_FILTER2 0x10000000 #define FEATURES_LISTMODE4 0x20000000 #define FEATURES_LISTMODE5 0x40000000 #define FEATURES_DEBUG_INFO 0x80000000 </pre>

⁷⁷ Since firmware version 16.00.

⁷⁸ The list mode 4 is planned in future firmware versions.

Command name	CMD_QUERY_STATE527_EX												
Compatibility	New MCA527 command.												
Execution right	Not necessary												
Description	The command reads the state.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	10	01	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	Common memory size [bytes] ⁷⁹						unsigned long						
Byte offset 4	Common memory fill stop [bytes]						unsigned long						
Byte offset 8	Common memory fill level [bytes]						unsigned long						
Byte offset 12	Oscilloscope time resolution						short						
Byte offset 14	Oscilloscope trigger source						unsigned short						
Byte offset 16	Oscilloscope trigger position						unsigned short						
Byte offset 18	Oscilloscope trigger threshold						unsigned short						
Byte offset 20	PUR counter						unsigned long						
Byte offset 24	Extension port part A configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 25	Extension port part B configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 26	Extension port part C configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 27	Extension port part D configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 28	Extension port part E configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 29	Extension port part F configuration						unsigned char		See CMD_SET_EXTENSION_PORT				
Byte offset 30	Extension port parts availability						unsigned char		Bit (0 ... 5): part (A ... F) is available Bit 6: Input signal (part E) can be looped through to output pin (part B).				
Byte offset 31	Extension port state flags						unsigned char						
Byte offset 32	Extension port polarity flags						unsigned char						
Byte offset 33	Highest allowed flattop time [* 0.1 μsec] ⁸⁰						unsigned char						
Byte offset 34	Size of the booting presets data structure ⁸¹						unsigned short						
Byte offset 36	Extension port pulser 1 period						unsigned long						
Byte offset 40	Extension port pulser 2 period						unsigned long						
Byte offset 44	Extension port pulser 1 width						unsigned long						
Byte offset 48	Extension port pulser 2 width						unsigned long						
Byte offset 52	Extension port RS232 baud rate						unsigned short		6 250 000 / value				
Byte offset 54	Extension port RS232 flags						unsigned short						

⁷⁹ The common memory size is not only depending on the hardware and firmware version but also on other operating conditions. If a micro SD memory card is plugged in the MCA527, additional memory is needed to operate it. This reduces the available common memory.

⁸⁰ Since firmware version 13.07.

⁸¹ Since firmware version 14.03.

Command name	CMD_QUERY_STATE527_EX (<i>1st Continuation</i>)		
Result data array			
Byte offset 56	Extension port counter 1	unsigned long	
Byte offset 60	Extension port counter 1 cps	unsigned long	
Byte offset 64	Extension port counter 1 of the previous sweep ⁸²	unsigned long	
Byte offset 68	Extension port counter 2	unsigned long	
Byte offset 72	Extension port counter 2 cps	unsigned long	
Byte offset 76	Extension port counter 2 of the previous sweep	unsigned long	
Byte offset 80	RS232 transfer buffer byte count	unsigned short	
Byte offset 82	Fractional digits ⁸³ of the real time [msec]	unsigned short	The integer part of the real time is returned by CMD_QUERY_STATE, byte offset 20.
Byte offset 84	PUR counter of the previous sweep	unsigned long	
Byte offset 88	Trigger filter availability flags ⁸⁴	unsigned long	Bit $n = 1$ means trigger filter n is available.
Byte offset 92	Trigger filter value1 [* 0.000 061 035 156 25]	short	According the selected trigger filter: (value2; value1) (value2; 0; value1) (value1; value2; value1) (value1; 0; value2; 0; value1)
Byte offset 94	Trigger filter value2 [* 0.000 061 035 156 25]	short	
Byte offset 96	TTL low level [* 0.1 V]	unsigned char	
Byte offset 97	TTL high level [* 0.1 V]	unsigned char	
Byte offset 98	Trigger level for automatic threshold calculation for direct input [* 0.0625]	unsigned short	80 ... 1600
Byte offset 100	ADC overflows per second ⁸⁵	unsigned long	
Byte offset 104	ADC sampling rate [kilohertz] ⁸⁵	unsigned short	
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	File size ⁸⁶ corresponding to setup [kilobytes]	unsigned short	
Byte offset 116	Total microSD card memory size [kilobytes]	unsigned long	
Byte offset 120	Free microSD card memory size [kilobytes] ⁸⁷	unsigned long	
Byte offset 124	File writing state	char	0 = idle, ≠0 = in process
Byte offset 125	Result of last file writing	char	-1 = not yet executed 0 = unsuccessful 1 = successful

82 Values which description ends with the string “of the previous sweep” refer either to the previously finished sweep during the repeat mode or to the last stopped measurement.

83 Since firmware version 13.04. If the value is returned during a running measurement, it should be treat with caution. Since the integer part of the real time is returned by another command, the user must consider the time difference between the commands.

84 Since firmware version 12.00.

85 Since firmware version 13.04.

86 This is the needed size on the microSD card.

87 This is the free microSD card memory size minus the size of one cluster that is reserved for a potential expansion of the directory.

Command name	CMD_QUERY_STATE527_EX (2 nd Continuation)		
Result data array			
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	RS485 bus baud rate ⁸⁸	unsigned short	6 250 000 / value

⁸⁸ Since firmware version 15.03.

Command name	CMD_QUERY_STATE527_EX2												
Compatibility	New MCA527 command (since firmware version 14.00).												
Execution right	Not necessary												
Description	The command reads the state.												
Format	integer		integer		integer		long				integer		
Parameter	preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	2F	01	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	AHRC group 0 width						unsigned long		See CMD_SET_AHRC_PARAM				
Byte offset 4	AHRC group 1 width						unsigned long						
Byte offset 8	AHRC group 2 width						unsigned long						
Byte offset 12	AHRC group 3 width						unsigned long						
Byte offset 16	AHRC group 4 width						unsigned long						
Byte offset 20	AHRC group 5 width						unsigned long						
Byte offset 24	AHRC group 6 width						unsigned long						
Byte offset 28	AHRC group 7 width						unsigned long						
Byte offset 32	AHRC group 8 width						unsigned long						
Byte offset 36	AHRC group 9 width						unsigned long						
Byte offset 40	AHRC trigger threshold						unsigned short						
Byte offset 42	MCS time per channel for gating mode 'sort by time' ⁸⁹						unsigned short		See CMD_SET_GATING_TIME_PER_CHANNEL				
Byte offset 44	Time window 0 width for gating mode 'sort by time' ⁹⁰						unsigned long		See CMD_SET_GATING_TIME_WINDOW_WIDTH				
Byte offset 48	Time window 1 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 52	Time window 2 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 56	Time window 3 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 60	Time window 4 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 64	Time window 5 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 68	Time window 6 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 72	Time window 7 width for gating mode 'sort by time' ⁹⁰						unsigned long						
Byte offset 76	Extension port pulser 3 period ⁹¹						unsigned long						
Byte offset 80	Extension port pulser 3 width ⁹¹						unsigned long						
Byte offset 84	Extension port counter 3 ⁹¹						unsigned long						
Byte offset 88	Extension port counter 3 cps ⁹¹						unsigned long						
Byte offset 92	Extension port counter 3 of the prev. sweep ^{91 92}						unsigned long						

⁸⁹ Since firmware version 16.00.

⁹⁰ Since firmware version 14.02.

⁹¹ Since firmware version 15.06. Micro version only.

⁹² Values which description ends with the string "of the previous sweep" refer either to the previously finished sweep during the repeat mode or to the last stopped measurement.

Command name	CMD_QUERY_STATE527_EX2 (Continuation)		
Result data array			
Byte offset 96	Add. temperature 1 [* 0.007 812 5 °C] ^{93 94}	short	0x8000 = not available
Byte offset 98	Add. temperature 1 [* 0.007 812 5 °C] of the previous sweep ^{93 94}	short	0x8000 = not available
Byte offset 100	Add. temperature 2 [* 0.007 812 5 °C] ^{93 95}	short	0x8000 = not available
Byte offset 102	Add. temperature 2 [* 0.007 812 5 °C] of the previous sweep ^{93 95}	short	0x8000 = not available
Byte offset 104	Flattop time 2 [* 0.1 µsec] ⁹⁶	unsigned short	See CMD_SET_FLAT_TOP_TIME
Byte offset 106	Command flag and parameters	8 bytes	
Byte offset 114	Evaluation filter 2 size ⁹⁶	unsigned short	
Byte offset 116	Internal fine gain set by the stabilization routine ⁹⁷	unsigned long	
Byte offset 120	MCA features (2 nd group) ⁹⁷	unsigned long	
Byte offset 124	Minimum event distance	unsigned short	See CMD_SET_MINIMUM_EVENT_DISTANCE
Byte offset 126	Checksum	unsigned short	
Byte offset 128	MCA state	unsigned short	See CMD_QUERY_POWER
Byte offset 130	unused	2 bytes	
Remarks	<p>The different hardware and firmware versions of the MCA527 support different features. The value "MCA features (2nd group)" (byte offset 120) gives detailed information about the supported features. The first group of the MCA features is returned by CMD_QUERY_STATE527 (byte offset 8).</p> <p>FEATURES2_MINIMUM_EVENT_DISTANCE⁹⁷: This flag indicates that the MCA527 supports CMD_SET_MINIMUM_EVENT_DISTANCE.</p> <p>FEATURES2_SLOW_RISE⁹⁷: This flag indicates that the MCA527 supports an evaluation filter for slow rising signals. If set, this evaluation filter can be chosen with CMD_SET_EVAL_FILTER_TYPE.</p> <p>Decoding:</p> <pre>#define FEATURES2_MINIMUM_EVENT_DISTANCE 0x00000001 #define FEATURES2_SLOW_RISE 0x00000002</pre>		

93 Since firmware version 15.06. Micro and OEM version only.

94 Additional external temperature sensor at the two-wire interface with address 1001 0000. The sensor must be a TMP102 (Micro) or LM73 (OEM).

95 Additional external temperature sensor at the two-wire interface with address 1001 0110 (Micro) or 1001 1000 (OEM). The sensor must be a TMP102 (Micro) or LM73 (OEM).

96 Since firmware version 16.00.

97 Since firmware version 19.00.

Command name	CMD_QUERY_USER_DATA											
Compatibility	Compatible to the MCA166 command.											
Execution right	Not necessary											
Description	The command reads sixteen 32 bit values from the MCA memory. e: 0 ... 255 start entry number											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		e		0				end flag	
Byte string (HEX)	A5	5A	5E	00	e	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Sixteen 32 bit values						32 bit [16]					
Byte offset 64	unused						42 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						12 bytes					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	unused						4 bytes					

Command name	CMD_QUERY_SPECTRA											
Compatibility	Compatible to the MCA166 command.											
Execution right	Conditionally necessary (see buffer control and remarks)											
Description	The command reads the spectrum data. n: Number of first channel and buffer control (Bit 15 ... 12) c: Compress factor (1 ... 128)											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		n		c		0		end flag	
Byte string (HEX)	A5	5A	5B	00	n _l	n _h	c _l	c _h	00	00	B9	9B
Buffer control	See CMD_QUERY_SPECTRA_EX (next command).											
Result data array												
Byte offset 0	Channels counts						unsigned long [32]					
Byte offset 128	Buffer state						unsigned short		OCCUPIED		= 0x2000	
									OVERRUN		= 0x4000	
									FILLED		= 0x8000	
Byte offset 130	Checksum ⁹⁸						unsigned short					
Remarks	The compress factor determines how many channels each are combined to one value. This value is the maximum of the combined channels. The transfer of combined channels can be used to reduce data transfer if the data are only intended for displaying the accumulation of the spectrum during a measurement. If the spectrum data are intended for evaluation, the whole spectrum with compress factor 1 has to be transferred. See also the remarks of CMD_QUERY_SPECTRA_EX (next command).											

⁹⁸ This checksum is calculated differently from the other commands. See the introduction at the beginning of the document.

Command name	CMD_QUERY_SPECTRA_EX											
Compatibility	New MCA527 command.											
Execution right	Conditionally necessary (see buffer control and remarks)											
Description	The command reads the spectrum data. n: Number of first channel c: Compress factor (1 ... 128) b: Buffer control: item [bit 4...0], index [bit 8...5], reserved [bit 13...9], flags [bit 15...14]											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		n		c		b		end flag	
Byte string (HEX)	A5	5A	02	01	n _l	n _h	c _l	c _h	b _l	b _h	B9	9B
Buffer control (item)	The buffer control applies to CMD_QUERY_SPECTRA and CMD_QUERY_SPECTRA_EX, but items higher than 15 are only usable with CMD_QUERY_SPECTRA_EX.											
	Item	Meaning					MCA mode		MCS mode		Execution right	
	0	Read spectrum					available		available		not necessary	
	1	Read MCS amplitude spectrum					not available		available		not necessary	
	2	Read spectrum buffer and unlock buffer					available		available		necessary	
	3	Read spectrum buffer and lock buffer					available		available		necessary	
	6	Read MCS amplitude spectrum buffer and unlock buffer					not available		available		necessary	
	7	Read MCS amplitude spectrum buffer and lock buffer					not available		available		necessary	
	8	Read rejected spectrum					available		available		not necessary	
	9	Read rejected MCS amplitude spectrum					not available		available		not necessary	
	10	Read rejected spectrum buffer and unlock buffer					available		available		necessary	
	11	Read rejected spectrum buffer and lock buffer					available		available		necessary	
	14	Read rejected MCS amplitude spectrum buffer and unlock buffer					not available		available		necessary	
	15	Read rejected MCS amplitude spectrum buffer and lock buffer					not available		available		necessary	
	17	Read MCS counter1 spectrum					not available		available		not necessary	
	18	Read MCS counter1 spectrum buffer and unlock buffer					not available		available		necessary	
	19	Read MCS counter1 spectrum buffer and lock buffer					not available		available		necessary	
	21	Read MCS counter2 spectrum					not available		available		not necessary	
	22	Read MCS counter2 spectrum buffer and unlock buffer					not available		available		necessary	
	23	Read MCS counter2 spectrum buffer and lock buffer					not available		available		necessary	

Command name	CMD_QUERY_SPECTRA_EX (Continuation)				
Buffer control (item)	Item	Meaning	MCA mode	MCS mode	Execution right
	25	Read MCS counter3 spectrum ⁹⁹	not available	available	not necessary
	26	Read MCS counter3 spectrum buffer and unlock buffer ⁹⁹	not available	available	necessary
	27	Read MCS counter3 spectrum buffer and lock buffer ⁹⁹	not available	available	necessary
Buffer control (index ^{100 101})	The index is only relevant for gating mode 'sort by time'. If the gating mode is not 'sort by time', the index should be zero. Indices 0 ... 7 refer to the MCA spectra and index 15 refers to the MCS spectrum. The indices 8 ... 14 are not allowed. See also command CMD_SET_GATING.				
Buffer control (reserved ¹⁰⁰)	The reserved bits should by zero.				
Buffer control (flags)	Bit 15: 0 = maximum of the compressed channels 1 = sum of the compressed channels ¹⁰² Bit 14: 0 = 32 channels [unsigned long] 1 = 64 channels [unsigned short] ¹⁰³				
Result data array					
Byte offset 0	Channels counts	unsigned long [32] or unsigned short [64]	The data format is depending on bit 14 of buffer control.		
Byte offset 128	Buffer state	unsigned short	OCCUPIED OVERRUN FILLED	= 0x2000 = 0x4000 = 0x8000	
Byte offset 130	Checksum ¹⁰⁴	unsigned short			
Remarks	<p>This command has been added because CMD_QUERY_SPECTRA does not support more than 4096 channels and its buffer control parameter is limited.</p> <p>If the MCA527 measures in repeat mode, the execution right is necessary, no matter the value of buffer control.</p> <p>The capability to lock and unlock the buffer is relevant if the MCA527 measures in repeat mode. It is also used with the command CMD_QUERY_EXTENSION_RS232_RX.</p> <p>Locking the buffer makes sure that the buffer is not overwritten with the data of the next measuring cycle before the buffer is not unlocked again.</p> <p>If the MCA527 measures in a repeat mode which writes to the microSD memory card, the access to the buffer is denied. In this case the buffer is exclusively controlled by the MCA527.</p> <p>This remarks are also applicable for CMD_QUERY_SPECTRA.</p>				

⁹⁹ Since firmware version 15.06. Micro version only.

¹⁰⁰ Since firmware version 14.02

¹⁰¹ Since firmware version 16.00, the index is 4 bits long.

¹⁰² Since firmware version 12.03.

¹⁰³ Since firmware version 12.04.

¹⁰⁴ This checksum is calculated differently from the other commands. See the introduction at the beginning of the document.

Command name	CMD_QUERY_SPECTRA_EX2											
Compatibility	New MCA527 command (since firmware version 16.00).											
Execution right	Conditionally necessary (see buffer control and remarks of CMD_QUERY_SPECTRA_EX)											
Description	The command reads the spectrum data. The meaning of all parameters are identical to the parameters of CMD_QUERY_SPECTRA_EX. The difference between CMD_QUERY_SPECTRA_EX and CMD_QUERY_SPECTRA_EX2 is the number of the returned spectrum data bytes.											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		n		c		b		end flag	
Byte string (HEX)	A5	5A	38	01	n _l	n _h	c _l	c _h	b _l	b _h	B9	9B
Result data array												
Byte offset 0	Channels counts						unsigned long [256] or unsigned short [512]		The data format is depending on bit 14 of buffer control.			
Byte offset 1024	Buffer state						unsigned short		OCCUPIED = 0x2000 OVERRUN = 0x4000 FILLED = 0x8000			
Byte offset 1026	Command flag and parameters						8 bytes					
Byte offset 1034	Checksum						unsigned short					
Remarks	See the remarks of CMD_QUERY_SPECTRA_EX (previous command).											

Name	CMD_QUERY_EXTENSION_RS232_RX												
Compatibility	New MCA527 command.												
Execution right	Conditionally necessary (see remarks)												
Description	The command returns the last 1024 bytes received by the RS232 interface of the extension port. b: Buffer control: 0 = current data 1 = buffered data 2 = buffered data, unlock buffer 3 = buffered data, lock buffer												
Format	integer		integer		integer		long				integer		
Parameter	Preamble		command		b		0				end flag		
Byte string (HEX)	A5	5A	25	01	b _l	b _h	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	Number of bytes received since the last RS232 data transmission.												
Byte offset 2	Data						1024 bytes						
Byte offset 1026	Command flag and parameters						8 bytes						
Byte offset 1034	Checksum						unsigned short						
Remarks	If the MCA527 measures in repeat mode, the execution right is necessary. The capability to lock and unlock the buffer is relevant if the MCA527 measures in repeat mode. It is also used with the commands CMD_QUERY_SPECTRA and CMD_QUERY_SPECTRA_EX. Locking the buffer makes sure that the buffer is not overwritten with the data of the next measuring cycle before the buffer is not unlocked again. If the MCA527 measures in a repeat mode which writes to the microSD memory card, the access to the buffer is denied. In this case the buffer is exclusively controlled by the MCA527.												

Name	CMD_QUERY_HISTOGRAM											
Compatibility	New MCA527 command.											
Execution right	Not necessary											
Description	<p>The command causes the MCA to acquire a histogram from 500 000 ADC samples (= 50 ms).</p> <p>s: start (0 ... 16 384 – 256 * class interval width)</p> <p>c: class interval width (1, 2, 4 ... 64)</p> <p>The command is ignored and responds with an error value if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		s		c		0		end flag	
Byte string (HEX)	A5	5A	09	01	s _l	s _h	c	00	00	00	B9	9B
Result data array												
Byte offset 0	Sample counts within the 256 class intervals						unsigned long [256]					
Byte offset 1024	Command flag and parameters						8 bytes					
Byte offset 1032	Checksum						unsigned short					

Command name	CMD_QUERY_VOLTAGE_CURRENT											
Compatibility	Identical to the MCA166 command.											
Execution right	Not necessary											
Description	The command reads the voltages and currents.											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		0		0		0		end flag	
Byte string (HEX)	A5	5A	05	00	00	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Charger current [mA]						unsigned long					
Byte offset 4	HV primary current [mA]						unsigned long					
Byte offset 8	Battery current [mA]						unsigned long					
Byte offset 12	Battery voltage [mV]						unsigned long					
Byte offset 16	HV reference voltage [V]						unsigned long					
Byte offset 20	HV control voltage [V]						unsigned long					
Byte offset 24	+12V primary current [mA]						unsigned long					
Byte offset 28	+24V primary current [mA]						unsigned long					
Byte offset 32	-24V primary current [mA]						unsigned long					
Byte offset 36	-12V primary current [mA]						unsigned long					
Byte offset 40	unused						66 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						12 bytes					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	unused						4 bytes					

Command name	CMD_QUERY_CENTROID											
Compatibility	Identical to the MCA166 command.											
Execution right	Not necessary											
Description	The command reads the centroid of a ROI (beg<end, LLD<=beg, end<=ULD, end-beg<250).											
Format	integer		integer		integer		integer		integer		integer	
Parameter	preamble		command		beg		end		0		end flag	
Byte string (HEX)	A5	5A	5F	00	beg _l	beg _h	end _l	end _h	00	00	B9	9B
Result data array												
Byte offset 0	Peak centroid within the given ROI						float					
Byte offset 4	unused						102 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						12 bytes					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	unused						4 bytes					

Command name	CMD_QUERY_ENRICHMENT											
Compatibility	Identical to the MCA166 command.											
Execution right	Not necessary											
Description	<p>The command reads current dead time, real time and the integral of two ROIs. This is very useful during a running measurement because in this way there is no need for transferring parts of the spectrum data for calculating the ROI integrals itself. The name of the command refers to its original usage. The command is, of course, usable for all applications that need this information.</p> <p>r1b: ROI₁ begin r2b: ROI₂ begin r1l: ROI₁ length (8 ... 250 channels) r2l: ROI₂ length (8 ... 250 channels)</p>											
Format	integer		integer		char	char	integer		integer		integer	
Parameter	Preamble		command		r1l	r2l	r1b		r2b		end flag	
Byte string (HEX)	A5	5A	5D	00	r1l	r2l	r1b _l	r1b _h	r2b _l	r2b _h	B9	9B
Result data array												
Byte offset 0	Dead time						unsigned long					
Byte offset 4	Real time						unsigned long					
Byte offset 8	Integral of the 1 st ROI						unsigned long					
Byte offset 12	Integral of the 2 nd ROI						unsigned long					
Byte offset 16	unused						90 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						12 bytes					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	unused						4 bytes					

Name	CMD_QUERY_UF6_ROIS												
Compatibility	Identical to the MCA166 command.												
Execution right	Not necessary												
Description	The command reads begin and end of up to three ROIs that can be set by the command CMD_SET_UF6_ROIS. The name of the command refers to its original usage. See also the command CMD_QUERY_UF6_INFO.												
Format	integer		integer		integer		long				integer		
Parameter	Preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	65	00	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	1 st ROI begin						unsigned long						
Byte offset 4	1 st ROI end						unsigned long						
Byte offset 8	2 nd ROI begin						unsigned long						
Byte offset 12	2 nd ROI end						unsigned long						
Byte offset 16	3 rd ROI begin						unsigned long						
Byte offset 20	3 rd ROI end						unsigned long						
Byte offset 24	unused						82 bytes						
Byte offset 106	Command flag and parameters						8 bytes						
Byte offset 114	unused						12 bytes						
Byte offset 126	Checksum						unsigned short						
Byte offset 128	unused						4 bytes						

Name	CMD_QUERY_UF6_INFO											
Compatibility	Compatible to the MCA166 command.											
Execution right	Not necessary											
Description	The command reads current dead time, real time, the integral, begin and end of up to three ROIs. This is very useful during a running measurement because in this way there is no need for transferring parts of the spectrum data for calculating the ROI integrals itself. The name of the command refers to its original usage. The command is, of course, usable for all applications that need this information.											
Format	integer		integer		integer		long				integer	
Parameter	preamble		command		0		0				end flag	
Byte string (HEX)	A5	5A	66	00	00	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Dead time [msec]						unsigned long					
Byte offset 4	Real time [sec]						unsigned long					
Byte offset 8	Integral of the 1 st ROI						unsigned long					
Byte offset 12	Integral of the 2 nd ROI						unsigned long					
Byte offset 16	Integral of the 3 rd ROI						unsigned long					
Byte offset 20	1 st ROI begin						unsigned long					
Byte offset 24	1 st ROI end						unsigned long					
Byte offset 28	2 nd ROI begin						unsigned long					
Byte offset 32	2 nd ROI end						unsigned long					
Byte offset 36	3 rd ROI begin						unsigned long					
Byte offset 40	3 rd ROI end						unsigned long					
Byte offset 44	Fractional digits of the real time [msec] ¹⁰⁵						unsigned long		See CMD_QUERY_STATE527_EX, byte offset 82			
Byte offset 48	Area of the 1 st ROI ¹⁰⁵						unsigned long					
Byte offset 52	Area error of the 1 st ROI ¹⁰⁵						unsigned long					
Byte offset 56	Area of the 2 nd ROI ¹⁰⁵						unsigned long					
Byte offset 60	Area error of the 2 nd ROI ¹⁰⁵						unsigned long					
Byte offset 64	Area of the 3 rd ROI ¹⁰⁵						unsigned long					
Byte offset 68	Area error of the 3 rd ROI ¹⁰⁵						unsigned long					
Byte offset 72	unused						34 bytes					
Byte offset 106	Command flag and parameters						8 bytes					
Byte offset 114	unused						12 bytes					
Byte offset 126	Checksum						unsigned short					
Byte offset 128	unused						4 bytes					

¹⁰⁵Since firmware version 14.02.

Name	CMD_QUERY_COMMON_MEMORY																											
Compatibility	New MCA527 command.																											
Execution right	Not necessary																											
Description	The command reads 1440 bytes from the common memory. o: offset (0 ... common memory size / 2 – 720) The firmware multiplies the passed offset by two to get even memory addresses.																											
Format	integer		integer		long				integer		integer																	
Parameter	Preamble		command		o				0		end flag																	
Byte string (HEX)	A5	5A	07	01	o _l	o _h	00	00	B9	9B																
Result data array																												
Byte offset 0	1440 data bytes						1440 bytes																					
Byte offset 1440	Command flag and parameters						8 bytes																					
Byte offset 1448	Checksum						unsigned short																					
Remarks	<p>The common memory is used for the general modes</p> <p>1 = Transient recorder (records ADC raw data), 3 = List mode 1: Time stamp recorder (level triggered signals) 4 = List mode 2: Time stamp recorder (edge triggered signals) 5 = List mode 3: Time stamp recorder (AHRC = analog high rate counting)</p> <p>In the transient recorder mode, the common memory contains a sequence of 2 bytes long ADC raw data.</p> <p>In the list modes 1 to 3, the common memory contains a list of time intervals between two detected events. Each item is 1 to 4 bytes long. The bytes are arranged in big-endian order. The first byte always contains the code for the byte length of the value.</p> <table><tr><td>1 byte:</td><td>XXXXXXXX</td><td>0 ...</td><td>191</td></tr><tr><td>2 bytes:</td><td>11XXXXXX XXXXXXXX</td><td>192 ...</td><td>12479</td></tr><tr><td>3 bytes:</td><td>1111XXXX XXXXXXXX XXXXXXXX</td><td>12480 ...</td><td>798911</td></tr><tr><td>4 bytes:</td><td>111111XX XXXXXXXX XXXXXXXX XXXXXXXX</td><td>798912 ...</td><td>67907775</td></tr></table> <p>Each value represents the number of time units which are bygone since the previous event. Values of 67,907,775 means that no event has occurred for 67,907,775 time units. Only the next value less than 67,907,775 marks the next event. The time unit length can be calculated from the 'ADC sampling rate' (see CMD_QUERY_STATE527_EX, byte offset 104).</p>												1 byte:	XXXXXXXX	0 ...	191	2 bytes:	11XXXXXX XXXXXXXX	192 ...	12479	3 bytes:	1111XXXX XXXXXXXX XXXXXXXX	12480 ...	798911	4 bytes:	111111XX XXXXXXXX XXXXXXXX XXXXXXXX	798912 ...	67907775
1 byte:	XXXXXXXX	0 ...	191																									
2 bytes:	11XXXXXX XXXXXXXX	192 ...	12479																									
3 bytes:	1111XXXX XXXXXXXX XXXXXXXX	12480 ...	798911																									
4 bytes:	111111XX XXXXXXXX XXXXXXXX XXXXXXXX	798912 ...	67907775																									

Name	CMD_QUERY_OSCI_SCREEN												
Compatibility	New MCA527 command.												
Execution right	Necessary if the resolution index that is set with CMD_SET_OSCI_TRIGGER is larger than 0.												
Description	The command reads the data for the oscilloscope screen. p: -1 or the previously returned position												
Format	integer		integer		long				integer		integer		
Parameter	Preamble		command		p				0		end flag		
Byte string (HEX)	A5	5A	12	01	p _l	p _h	00	00	B9	9B	
Result data array													
Byte offset 0	Start position of the received data							unsigned long					
Byte offset 4	Start position of the subsequent data							unsigned long					
Byte offset 8	Data							unsigned short [500]					
Byte offset 1008	Command flag and parameters							8 bytes					
Byte offset 1016	Checksum							unsigned short					
Remarks	The oscilloscope mode is described in document: "MCA527 Oscilloscope Mode".												

Name	CMD_QUERY_OSCI_SCREEN_EX											
Compatibility	New MCA527 command.											
Execution right	Necessary if flags are set.											
Description	The command reads the data for the oscilloscope screen. Flags: Bit 0: convolve data with trigger filter Bit 1: convolve data with main filter											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		flags		0		0		end flag	
Byte string (HEX)	A5	5A	29	01	flags _l	flags _h	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Start position of the received data						unsigned long					
Byte offset 4	Data						unsigned short [720]					
Byte offset 1404	Command flag and parameters						8 bytes					
Byte offset 1412	Checksum						unsigned short					
Remarks	This command has been added to extend the features of the oscilloscope. Corresponding to the flags, the MCA527 convolves the data with the corresponding filters. The results can be subsequently read with the commands CMD_QUERY_OSCI_TRIGGER_FILTER_RESULTS and CMD_QUERY_OSCI_MAIN_FILTER_RESULTS. The command is only usable if the resolution index that is set with CMD_SET_OSCI_TRIGGER is not larger than 0. The oscilloscope mode is described in document: "MCA527 Oscilloscope Mode".											

Name	CMD_QUERY_OSCI_TRIGGER_FILTER_RESULTS											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command reads data that are calculated from the oscilloscope data during the last call of the command CMD_QUERY_OSCI_SCREEN_EX if the corresponding flag is set. Range: 0: results [0 ... 359] 1: results [360 ... 719]											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		range		0		0		end flag	
Byte string (HEX)	A5	5A	2A	01	range _e	range _n	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Applied trigger threshold [* 0.00006103515625]						long					
Byte offset 4	Results [* 0.00006103515625]						long [360]					
Byte offset 1444	Command flag and parameters						8 bytes					
Byte offset 1452	Checksum						unsigned short					
Remarks	In order to read all data, the command has to be called twice. The first time with range=0 and the second time with range=1. The oscilloscope mode is described in document: "MCA527 Oscilloscope Mode".											

Name	CMD_QUERY_OSCI_MAIN_FILTER_RESULTS											
Compatibility	New MCA527 command.											
Execution right	Necessary											
Description	The command reads data that are calculated from the oscilloscope data during the last call of the command CMD_QUERY_OSCI_SCREEN_EX if the corresponding flag is set.											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		0		0		0		end flag	
Byte string (HEX)	A5	5A	2B	01	00	00	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Results						short [720]					
Byte offset 1440	Jitter ¹⁰⁶						short					
Byte offset 1442	Command flag and parameters						8 bytes					
Byte offset 1450	Checksum						unsigned short					
Remarks	The oscilloscope mode is described in document: "MCA527 Oscilloscope Mode".											

¹⁰⁶The value is up to now unused. It is always 0.

Name	CMD_QUERY_AHRC_HISTOGRAM											
Compatibility	New MCA527 command (since firmware version 13.08).											
Execution right	Necessary											
Description	<p>The command causes the MCA to acquire a histogram from the areas of all detected events within an acquisition time of 0.8 seconds. The area is equivalent to the sum of the differences between the ADC value and the baseline from the point where the signal curve exceeds the threshold to the point where the signal curve falls below the threshold again.</p> <p>b: bin interval width (1, 2, 4 ... 32 768)</p> <p>The command is ignored and responds with an error value if the general mode is unequal to "Time stamp recorder (AHRC = analog high rate counting)" (= 5) or if a measurement is still running.</p>											
Format	integer		integer		integer		integer		integer		integer	
Parameter	Preamble		command		c		0		0		end flag	
Byte string (HEX)	A5	5A	31	01	b _l	b _h	00	00	00	00	B9	9B
Result data array												
Byte offset 0	Results						unsigned long [360]					
Byte offset 1440	Command flag and parameters						8 bytes					
Byte offset 1448	Checksum						unsigned short					
Remarks	The histogram is used to find the best values for the AHRC threshold and the AHRC group widths in an approximation procedure. The parameters can be set with CMD_SET_AHRC_PARAM. More about AHRC, see the remarks on this command.											

Name	CMD_QUERY_DETECTOR_INFO												
Compatibility	New MCA527 command (since firmware version 14.03).												
Execution right	Not necessary												
Description	The command returns 1024 bytes of the detector information. Range: 0: [0 ... 1023] 1: [1024 ... 2047]												
Format	integer		integer		integer		long				integer		
Parameter	Preamble		command		range		0				end flag		
Byte string (HEX)	A5	5A	33	01	range _l	range _h	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	Data						1024 bytes						
Byte offset 1024	Command flag and parameters						8 bytes						
Byte offset 1032	Checksum						unsigned short						
Remarks	There are detectors that supply detector information that are stored in an integrated EEPROM with a maximum size of 2048 bytes. The structure of the detector information is described in an extra document. The flag FEATURES_DETECTOR_INFO_VALID of the parameter “MCA features” (byte offset 8) returned by the command CMD_QUERY_STATE527 indicates if valid detector information are available.												

Name	CMD_QUERY_ADJUSTMENT_TABLE												
Compatibility	New MCA527 command.												
Execution right	Not necessary												
Description	The command returns the ADC values that has been measured with different settings at open signal input. These data can be used to interpolate the ADC value which corresponds to the ground line. A value is valid if it is unequal to -1.												
Format	integer		integer		integer		long				integer		
Parameter	Preamble		command		0		0				end flag		
Byte string (HEX)	A5	5A	26	01	00	00	00	00	00	00	B9	9B	
Result data array													
Byte offset 0	measured with coarse gain = 2, offset DAC = 1024						short						
Byte offset 2	measured with coarse gain = 2, offset DAC = 15360						short						
Byte offset 4	measured with coarse gain = 5, offset DAC = 1024						short						
Byte offset 6	measured with coarse gain = 5, offset DAC = 15360						short						
Byte offset 8	measured with coarse gain = 10, offset DAC = 1024						short						
Byte offset 10	measured with coarse gain = 10, offset DAC = 15360						short						
Byte offset 12	measured with coarse gain = 20, offset DAC = 1024						short						
Byte offset 14	measured with coarse gain = 20, offset DAC = 15360						short						
Byte offset 16	measured with coarse gain = 50, offset DAC = 1024						short						
Byte offset 18	measured with coarse gain = 50, offset DAC = 15360						short						
Byte offset 20	measured with coarse gain = 100, offset DAC = 1024						short						
Byte offset 22	measured with coarse gain = 100, offset DAC = 15360						short						
Byte offset 24	unused						82 bytes						
Byte offset 106	Command flag and parameters						8 bytes						
Byte offset 114	unused						12 bytes						
Byte offset 126	Checksum						unsigned short						
Byte offset 128	MCA state						unsigned short		See CMD_QUERY_POWER				
Byte offset 130	unused						2 bytes						